
Wall hung, fanflue, roomsealed, high efficiency gas boiler

User manual and Installation instructions

ANTARES

Product name

ANTARES 30S

Models

M300V.30 SR

G.C. Appl. No.

41-583-41



Congratulations on your choice.

The Biasi **ANTARES** are condensing high efficiency sealed chamber fan flue gas boilers. They are fully electronically controlled and have electronic ignition.

The materials they are made of and the control systems they are equipped with give you safety, a high level of comfort and energy savings to allow you to get the greatest benefit out of independent heating.

The Biasi **ANTARES** allow a higher efficiency by reducing the flue gas temperature such that the water vapour formed during the combustion is condensed out.

This allows a gain of useful heat that otherwise would be lost.



Biasi UK Ltd is a licensed member of the Benchmark Scheme which aims to improve the standards of installation and commissioning of domestic heating and hot water systems in the UK and to encourage regular servicing to optimise safety, efficiency and performance. Benchmark is managed and promoted by the Heating and Hot water Industry Council. For more information visit www.hhic.co.uk.



DANGER: The indications marked with this symbol must be observed to prevent accidents of mechanical or generic origin (e.g.: Injuries or bruises).



DANGER: The indications marked with this symbol must be observed to prevent accidents of electric origin (electrocution).



DANGER: The indications marked with this symbol must be observed to prevent the risk of fire or explosion.



DANGER: The indications marked with this symbol must be observed to prevent accidents of heat origin (burns).



ATTENTION: The indications marked with this symbol must be observed to prevent malfunctioning and/or damage to materials of the appliance or other objects.



ATTENTION: The indications marked with this symbol are important information that must be carefully read.



Remember that...



WARNING

- ✓ **The manual** must be read thoroughly, so that you will be able to use the boiler in a safe and sensible way and must be carefully kept. It may be necessary for reference in the future.
- ✓ **The first firing** must be carried out by a competent and responsible Gas Safe engineer.
- ✓ **The manufacturer**
 - disclaims all liability for any translations of the present manual from which incorrect interpretation may occur;
 - cannot be held responsible for non-observance of instructions contained in this manual or for the consequences of any procedure not specifically described.

Please ensure that the installer has fully completed the Benchmark Checklist on the inside back pages of the installation instructions supplied with the product and that you have signed it to say that you have received a full and clear explanation of its operation. The installer is legally required to complete a commissioning checklist as a means of complying with the appropriate Building Regulations (England and Wales).

All installations must be notified to Local Area Building Control either directly or through a Competent Persons Scheme. A Building Regulations Compliance Certificate will then be issued to the customer who should, on receipt, write the Notification Number on the Benchmark Checklist.

This product should be serviced regularly to optimise its safety, efficiency and performance. The service engineer should complete the relevant Service Record on the Benchmark Checklist after each service.

The Benchmark Checklist will be required in the event of any warranty claim.

- ✓ **Before lighting the boiler** you are advised to have a Gas Safe Registered Engineer check that the installation of the gas supply is
 - gas-tight;
 - of the correct gauge for the flow to the boiler;
 - fitted with all the safety and control devices required by the current Regulations.
- ✓ **Ensure that**
 - the installer has connected and terminated the pressure relief valve in a manner which allows safe discharge. The manufacturers are not responsible for damage caused by opening of the pressure relief valve and consequent escape of water, if this is not connected and terminated.
 - the installer has connected the condensate outlet to a suitable drain pipe.
 - ensure that all transit caps and protective packaging is removed.

✓ **On detecting the smell of gas:**

- do not operate any electrical switches, the telephone or any device that may produce sparks;
- open the windows and doors at once to create a draught of air which will purge the area;
- shut off the gas cocks;
- get the assistance of a qualified person. Emergency telephone number

Tel. 0800 111999.

- ✓ **Do not touch the appliance** with parts of the body that are wet or damp and/or bare feet.
- ✓ **Do not block or modify** the condensate outlet and pipe work.
- ✓ **In case of structural work** or maintenance near the flue and flue terminal turn off the appliance. On completion of the work, have a professionally qualified person check there efficiency.
- ✓ **Repairs** (under guarantee) must be carried out only by a Biasi an approved engineer, using genuine spare parts. Thus do no more than switching off the boiler yourself (see the instructions).
- ✓ **Your boiler** allows heating up of water to a temperature less than boiling point therefore it
 - must be connected to a central heating system and/or a hot water supply system, compatible with its performance and output;
 - can be used only for those purposes for which it has been specially designed;
 - must not be touched by children or by those unfamiliar with its operation;
 - must not be exposed to weather conditions.
- ✓ **During the operation** it is quite normal that the boiler produces a white plume of condensation vapour from the flue terminal. This is due to the high efficiency of the appliance and may be particularly evident with low outdoor temperatures.

Safe handling of substances

Biasi products are manufactured in accordance with ISO 9001 and do not, and will not, contain any hazardous materials or substances such as asbestos, mercury or C.F.C.'s. The appliance packaging does not contain any substances, which may be considered a hazard to health.

When handling or lifting always use safe techniques.

- Keep your back straight, bend your knees, don't twist.
- Move your feet, avoid bending forwards and side ways and keep the load as close to your body as possible.

Where possible transport the boiler using a sack truck or other suitable trolley.

Always grip the boiler firmly, and before lifting feel where the weight is concentrated to establish the centre of gravity, repositioning yourself as necessary.

Combustion chamber panels

Material: mineral fibres

Known hazards - Some people can suffer reddening and itching of the skin. Fibre entry into the eye will cause foreign body irritation, which can cause severe irritation to people wearing contact lenses. Irritation to respiratory tract.

Precautions - Dust goggles will protect eyes. People with a history of skin complaints may be particularly susceptible to irritation. High dust levels are only likely to arise following harsh abrasion. In general, normal handling and use will not present high risk. Follow good hygiene practices; wash hands before, touching eyes, consuming food, drinking or using the toilet.

First aid - Medical attention must be sought following eye contact or prolonged reddening of the skin.

Sharp Edges

Caution should be taken when handling the boiler to avoid sharp edges on the boiler.

Boiler installation and commissioning tips

- ✓ **The installation** must be carried out by a qualified Gas Safe Registered Engineer who will be responsible for observing the current Regulations and the completion of the Benchmark Gas Boiler System Commissioning Checklist, located at the back of this User manual.

Installing the boiler...

- ✓ You must ensure that you remove the transit caps and plugs from the boiler connections which are fitted to every boiler.
- ✓ Keep the boiler clear of dust during installation and in particular do not allow any dust or debris to enter the top of the boiler where the flue connection is made. It is recommended that you put a dust sheet over the top of the boiler until you are ready to make the flue connection.
- ✓ Remember to release the auto air purge valve on the pump assembly before filling the boiler. See the instructions to identify the location of this device.
- ✓ This boiler allows you to control the flow temperature of the central heating system at very low levels. For underfloor heating system a temperature limiting device (e.g. a safety thermostat) is recommended to stop the boiler in case that the water temperature exceeds the design temperature.
- ✓ You are strongly advised to flush out the system both hot and cold in order to remove any system and installation debris to the British Standard BS 7593 code of practice.
- ✓ It is also sensible to initially fire and commission the boiler before connecting any external controls such as a room thermostat. By following this procedure, if you have a subsequent problem this method can eliminate the external controls from your fault analysis.
- ✓ Some products incorporate an anti cycling time delay. It is normal when first switching the boiler on for the boiler to operate on heating for a few seconds then switch off. After 3 - 4 minutes has elapsed the boiler will then re ignite and operate perfectly normally.
- ✓ If you are in any doubts as to the installation or operation of the boiler please read the instruction manuals thoroughly and then if necessary contact Biasi UK for advice and assistance.
- ✓ Guarantee conditions.
The guarantee registration form must be returned within 30 days of purchase, failure to comply will invalidate the guarantee.
Electrodes disclaimer. Note to service engineers: It is required that the burner seal, lip seal and mixing chamber seal along with the flame detection electrode are inspected every year and replaced every 24 months. Failure to inspect the flame detection probe, seals and replace as required may render the guarantee void.

Please remember that if you are in any doubt about the installation of this product you can contact our Technical Help line on tel. 01922 714 600.

Appliance category: II2H3P (gas G20 20 mbar, G31 37 mbar)

Country of destination: United Kingdom (GB) Ireland (IE)

This appliance conforms with the following EEC directive:

Regulation (EU) 2016/426 on appliances burning gaseous fuels

Efficiency Directive 92/42/EEC

Electromagnetic Compatibility Directive 2014/30/EU

Low Voltage Directive 2014/35/EU

Ecodesign Requirements Directive 2009/125/EC

The manufacturer, in the continuous process to improve his products, reserves the right to modify the data expressed in the present documentation at any time and without prior notice.

The present documentation is an informative support and it can not be considered as a contract towards third parties.

TABLE OF CONTENTS

1 APPLIANCE DESCRIPTION	8	6.12 Electric connection between the boiler and the external probe	52
1.1 Overview	8	6.13 Remote electric connection (optional)	52
1.2 Isolation valves	8	6.14 Example of hydraulic systems with hydraulic separator	52
1.3 Control panel	9		
1.4 LCD general features	9	7 COMMISSIONING	54
1.5 LCD display settings (language, time, date, etc.)	12	7.1 Warnings	54
2 INSTRUCTIONS FOR USE	14	7.2 Electrical installation	54
2.1 Warnings	14	7.3 Gas supply installation	54
2.2 Refilling procedure	14	7.4 Initial filling of the system	54
2.3 Ignition	15	7.5 Condensate pipe and traps	57
2.4 Adjusting the temperature of the C.H.	16	7.6 Checking the gas supply pressure	57
2.5 Setting time brackets (Schedules)	16	7.7 Checking the inlet pressure	57
2.6 Setting heating (Zones)	17	7.8 Lighting the boiler	58
2.7 Setting daily programming	19	7.9 Checking the ignition device	60
2.8 Fault and anomaly signals	21	7.10 Checking the flue system	60
2.9 Shutdown	21	7.11 Checking the condensate drain pipe	60
2.10 Reset / User factory settings	22	7.12 Instructing the user	60
3 USEFUL ADVICE	24	8 ADVANCED COMMISSIONING	61
3.1 Central Heating	24	8.1 Accessing the "Service" menu (Installer)	61
3.2 Frost protection	24	8.2 Selecting the type of external sensor	62
3.3 Condensate drain	24	8.3 Enabling operation with the external sensor and setting the K coefficient of the external temperature probe	63
3.4 Periodic maintenance	24	8.4 Selecting minimum/maximum heating temperature	65
3.5 External cleaning	25	8.5 Setting pump post-circulation	66
3.6 Operational faults	25	8.6 Selecting the reignition frequency	67
3.7 Fault history	26	8.7 Reset / "Service" factory settings (installer)	68
3.8 Displaying in INFO mode	28	8.8 Boiler adjustment record	70
3.9 Remote anomaly code	29	9 GAS CONVERSION	72
3.10 Flue probe and safety thermal fuse	29	9.1 Warnings	72
4 TECHNICAL INFORMATION	30	9.2 Operations and gas setting	72
4.1 Overview	30	10 MAINTENANCE	74
4.2 Main diagram	31	10.1 Warnings	74
4.3 Hydraulic specifications	33	10.2 Programming the maintenance period	74
4.4 Expansion vessel	33	10.3 Dismantling the external panels	75
4.5 Technical data ANTARES 30S (M300V.30 SR)	34	10.4 Reassembly the external panels	76
5 GENERAL REQUIREMENTS	37	10.5 Emptying the C.H. system	76
5.1 Related documents	37	10.6 Cleaning the condensing primary exchanger and the burner	77
5.2 Location of appliance	37	10.7 Check the pressure of the heating expansion vessel	78
5.3 Flue system	38	10.8 Checking the flue system	78
5.4 Gas supply	39	10.9 Combustion analysis check	78
5.5 Air supply	40	10.10 Checking the condensate drain pipe	79
5.6 Ventilation	40	10.11 Visual inspection of appliance	79
5.7 Condensate drain	40	10.12 Checking the gas supply pressure	79
5.8 Water circulation (C.H.)	41	10.13 Water inhibitor concentration	80
5.9 Water treatment	42	10.14 Setting the boiler flue sweep function	80
5.10 Electrical supply	42	11 BENCHMARK COMMISSIONING & WARRANTY VALIDATION SERVICE RECORD	82
6 INSTALLATION	43	Gas boiler system commissioning checklist & warranty validation record	83
6.1 Warnings	43	Service & interim boiler work record	84
6.2 Precautions for installation	43		
6.3 Installing the bracket	44		
6.4 Overall dimensions	45		
6.5 Joints	45		
6.6 Mounting the boiler	45		
6.7 Fitting the flue system	46		
6.8 Choice of flue	46		
6.9 Electric connection	49		
6.10 Connecting the room thermostat or zone valves	51		
6.11 Installation of the external temperature probe	51		

Abbreviations used in the manual:

C.H. = Central heating
D.H.W. = Domestic hot water
D.C.W. = Domestic cold water

APPLIANCE DESCRIPTION

1 APPLIANCE DESCRIPTION

1.1 Overview

The model and serial number of the boiler is shown on the bottom of the boiler.




Fig. 1.1

1 Controls panel

1.2 Isolation valves

The figures in this manual only show one of the possible ways of installing cocks, pipes and fittings.




Fig. 1.2

- 2 Gas supply label
- 3 Condensate drain pipe
- 4 C.H. flow valve
- 5 Gas inlet valve
- 6 C.H. pressure relief valve pipe
- 7 Main circuit drain valve
- 8 C.H. return valve
- 9 Model and serial number of the boiler label

APPLIANCE DESCRIPTION

1.3 Control panel




Fig. 1.3

- 10 Programming key
- 11 Programming key
- 12 Reset/Stand-by/Winter/Summer key
- 13 Confirm / Menu key
- 14 Back / Exit key
- 15 C.H. temperature reduce key
- 16 C.H. temperature increase key
- 17 LCD display



If no keys are pressed for 10 seconds, the keypad goes to stand-by (keys off).

Press any key to reactivate the keypad (keys on) and wait at least 1 second for all keys to be fully operational.

1.4 LCD general features

For the boiler technical information refer to the section "TECHNICAL INFORMATION" on page 30.




Fig. 1.4






- 18 Info on system pressure
- 19 Output scale (Burner output scale with boiler active)
- 20 Display of delivery temperature / fault code
- 21 System status
- 22 Heating set display
- 23 Display of general system icons

KEY












	Modbus communication BUS connection.
	Icon showing zone remote panel presence.
	Connecting the external probe.
	Water pressure within correct range.
	System water pressure below minimum.
	Heating function enabled (winter).
	Heating function in progress.
	Outdoor temperature.

















USE

APPLIANCE DESCRIPTION












	Zone identification icon.
	Zone identification icon with request in progress.
	OFF mode.
	Stand-by mode.
	Anomaly detected icon.








SIGNAL DISPLAYED BY THE LCD

LCD	FUNCTION
1 + 	Safety lockout due to failed ignition.
2 + 	Lockout due to safety thermostat.
3 + 	Generic lockout.
4 + 	Pump circulation failure, insufficient system pressure or pressure above 3 bar, water pressure sensor not connected.
5 + 	Control fault: fan.
6 + 	NTC heating delivery probe failure.
7 + 	D.H.W. NTC probe failure / Hot water tank sensor failure.
8 + 	External NTC probe failure.
10 + 	Lockout due to tripping of the flue gas probe and thermal fuse.
11 + 	Parasite flame.
12 + 	Return NTC probe failure.

LCD	FUNCTION
13 + 	Delta T M-R > 40K.
14 + 	Pump fault or primary temperature above 105°C.
14 + 	Temperature gradient circulation failure (>2K/s).
15 + 	Probable insufficient circulation.
16 + 	Flue gas overheating detected by NTC.
18 + 	No ΔT heating at start-up.
19 + 	Auxiliary Input Probe Anomaly.
20 + 	EVG lockout (valve piloting hardware failure).
21 + 	EVG lockout (valve control Relay Failure).
22 + 	EVG lockout (flame after closing valve Ref. EVG).
23 + 	Gas valve modulator disconnected.
24 + 	Anomaly due to probable chimney obstruction.
25 + 	Flame loss for more than 6 consecutive times.
26 + 	Maximum deviation fault between the 2 heating NTC probes.
40 + 	Incorrect mains electrical supply frequency.
42 + 	Keys fault.

APPLIANCE DESCRIPTION

LCD	FUNCTION
44 + 	Fault of cumulative gas valve timeout without flame. Heating water low pressure fault, pressure below minimum.
50 + 	OT communication fault.
62 + 	Calibration request.
65 + 	System fails to control combustion and exits modulator control parameters.
68 + 	Probable low gas pressure.
77 + 	System out modulator control parameters.
78 + 	Probable low gas pressure.
79 + 	System out modulator control parameters.
89 + 	Internal error (usually hardware) or problems with the mains electrical supply (excessive distortion of waveform).
91 + 	Maximum number of lockouts reached.
96	Incorrect network frequency.
96 + 	After 5 E02 - E14 - E04 - E15 - E16 error events, the boiler goes into lockout.
97	Power supply voltage low.
99	Card not configured.
L1	Primary limitation in D.H.W. mode.

LCD	FUNCTION
	Boiler in Stand-By, the symbol shown in the figure appears (anti-freeze protection active).
	When powering ON the boiler, this sequence appears (for 2 seconds).
	The symbol shown in the figure appears if the pressure is incorrect.
	Boiler with D.H.W. power request.
	Boiler with central heating request via room thermostat.
	Boiler with central heating power request with connected remote.
	Eco function NOT active.

APPLIANCE DESCRIPTION

1.5 LCD display settings (language, time, date, etc.)

- Power the boiler by turning on the two-way switch fitted during installation. The LCD display shows the boiler status (last stored).



Fig. 1.5

- Press key 13 (Fig. 1.5) to access the main menu (Fig. 1.6).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 1.6

- Press key 10 or 11 (Fig. 1.5) to select the desired menu (Fig. 1.7).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 1.7

- Press key 13 (Fig. 1.5) to access the selected menu (Fig. 1.8).

- Press key 13 (Fig. 1.5) again to highlight the value to be changed.
- Press key 15 or 16 (Fig. 1.5) to select the desired language from those available (Fig. 1.8).

General settings	
Language	ITA
Display	[...]
Access level	[...]
User factory settings	[...]

Fig. 1.8

- Press key 13 (Fig. 1.5) to confirm the change or key 14 to exit without changing the value (return to previous level).
- Press key 14 (Fig. 1.5) to return to the previous level (Fig. 1.7).
- Press key 10 or 11 (Fig. 1.5) to select the desired menu (Fig. 1.9).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 1.9

- Press key 13 (Fig. 1.5) to access the selected menu (Fig. 1.10).

Clock and programmes	
Set date and time	[...]
Aut. daylight saving time	Yes
Schedules	[...]
Program Zone 1	[...]
DHW Program	[...]
Holiday Program	Off

Fig. 1.10

APPLIANCE DESCRIPTION

- Press key 13 (Fig. 1.5) to access the selected menu (Fig. 1.11).
- Press key 13 (Fig. 1.5) again to highlight the value to be changed.
- Press key 10 or 11 (Fig. 1.5) to select the desired menu (Fig. 1.11).
- Press key 15 or 16 (Fig. 1.5) to enter the desired value (Fig. 1.11).

Set date and time	
HOUR	14:30
DAY	30
MONTH	11
YEAR	2023

Fig. 1.11

- Press key 13 (Fig. 1.5) to confirm the change or key 14 to exit without changing the value (return to previous level).
- Press key 14 (Fig. 1.5) repeatedly to return to the level in Fig. 1.8.
- Press key 10 or 11 (Fig. 1.5) to select the desired menu (Fig. 1.12).

General settings	
Language	ITA
Display	[...]
Access level	[...]
User factory settings	[...]

Fig. 1.12

- Press key 13 (Fig. 1.5) to access the selected menu (Fig. 1.13).
- Press key 13 (Fig. 1.5) again to highlight the value to be changed.
- Press key 15 or 16 (Fig. 1.5) to enter the desired value (Fig. 1.13).

Display	
Contrast	5
Display lighting	Auto
Display current value	CH&DHW
Keypad tones	Yes

Fig. 1.13

- Press key 13 (Fig. 1.5) to confirm the change or key 14 to exit without changing the value (return to previous level).



With "Display lighting" set to Off, the display is always off. Press any key to illuminate the display on maximum brightness for 10 seconds.

Key 12 (Fig. 1.5) remains lit to signal the appliance is powered.

USE

INSTRUCTIONS FOR USE

2 INSTRUCTIONS FOR USE

2.1 Warnings

Biasi UK Ltd support the Benchmark initiative. The Benchmark Checklist is located at the back of this manual and should be completed by the Installing/Commissioning Engineer and handed over to the User for future reference by other visiting Engineers.

Also included is the Service Interval Record card that should be completed by the Service Engineer following the annual service maintenance of the boiler and system.

All Gas Safe Registered Installers carry a Gas Safe ID card, and have a registration number. Both should be recorded in your Benchmark Checklist. You can check your Installer is registered by calling Gas Safe direct on 0800 408 5500, or go on line at www.GasSafeRegister.co.uk.

In order to guarantee safety and correct operation, it is essential that all the tests are carried out by a competent and responsible service engineer before lighting up the boiler.

The tests are described in the installation instructions in section "COMMISSIONING" on page 54 commissioning.

Ensure that the C.H. circuit is regularly filled with water.

If the pressure reading on the pressure gauge is below that shown in Fig. 2.2, then the system will require topping up. A filling loop is normally provided by the Installer for this purpose.

If you are in any doubt regarding this procedure you are advised to contact your Installer or an Approved Engineer.

This appliance is provided with a built in

anti-freeze system that operates the boiler when the temperature is below 5 °C.

Therefore, when the boiler is not lit or used in cold weather, with consequent risk of freezing do not switch off the boiler at the fused spur isolation switch or close the gas inlet cock.



In a non permanent live connection format this option will not function. An alternative solution can be an external frost thermostat connected through your wiring center.

When you do not expect to use the boiler for a long period and the boiler is not to be used for frost protection then follow the instructions given in section "Shutdown" on page 21.

If you experience any difficulty with the operation of the boiler, switch off the boiler immediately at the fused spur isolation switch and contact your Installer or an approved Service Engineer.

You may find it necessary to vent air from your radiator circuit using your radiator key.

2.2 Refilling procedure

- Isolate the boiler from the electrical supply at the fused spur. Reconnect the filling loop as demonstrated in Fig. 2.1.




Fig. 2.1

INSTRUCTIONS FOR USE

Press any key to activate the display.
The heating circuit pressure is shown at the top of the display (Fig. 2.2).




Fig. 2.2

- Open the valves on the filling loop and, at the same time, check the heating circuit pressure on the display.
The pressure must be between 1 bar and 1.5 bar (e.g. 1.3 bar in (Fig. 2.2)).

Once done, close the valves on the filling loop.

If you experience any difficulty with the operation of the boiler, switch off the boiler immediately at the fused spur isolation switch and contact your Installer or an approved Service Engineer.

Air introduced into the boiler during this filling process will vent through the automatic air purger fitted to the boiler. You may also find it necessary to vent air from your radiator circuit using your radiator key, however be aware that excessive venting will cause the pressure in the system to drop.

Always ensure that the pressure gauge is set at the required pressure.

2.3 Ignition

- Check that the valves located in the lower part of the boiler are open (Fig. 2.3).






Fig. 2.3

- Turn on the electricity supply to the boiler, switching on the fused spur isolation switch. The LCD display displays the state within which the boiler is found (last memorised) Fig. 2.4.



OFF

Boiler off, all functions deactivated.



Stand-by

Only anti-freeze function active.



Winter

Heating and anti-freeze functions active.

Fig. 2.4

INSTRUCTIONS FOR USE

When the boiler is OFF, key 12 (Fig. 2.5) must be held down for at least 4 seconds to reactivate it.

To select the various operating modes, simply press key 12 (Fig. 2.5) repeatedly and select the desired mode (see Fig. 2.4).

2.4 Adjusting the temperature of the C.H.

The heating delivery hot water temperature can be adjusted from a minimum of approx. 25°C to a maximum of approx. 80°C.

Your qualified installer may suggest more suitable settings for your system.

To set the desired temperature, simply press key 15 or 16 for heating system water.



Fig. 2.5

It is also possible to set 4 schedules containing 4 time brackets for operating in comfort mode. Outside these 4 time brackets, the system will run in economy mode (see "Setting time brackets (Schedules)" on page 16).

2.5 Setting time brackets (Schedules)

It is possible to set 4 schedules containing 4 time brackets for operating in comfort mode. Outside these 4 time brackets, the system will run in economy mode (see "Setting heating (Zones)" on page 17).




Fig. 2.6

- Press key 13 (Fig. 2.6) to access the main menu (Fig. 2.7).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 2.7

- Press key 10 or 11 (Fig. 2.6) to select the desired menu (Fig. 2.8).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 2.8

- Press key 13 (Fig. 2.6) to access the selected menu (Fig. 2.9).

INSTRUCTIONS FOR USE

Clock and programmes	
Set date and time	[...]
Aut. daylight saving time	Yes
Schedules	[...]
Program Zone 1	[...]
DHW Program	[...]
Holiday Program	Off

Fig. 2.9

- Press key 10 or 11 (Fig. 2.6) to select the schedule to be modified (1 to 4) (Fig. 2.10).
- Press key 15 or 16 (Fig. 2.6) to access the time brackets (1 to 4).
- Press key 10 or 11 (Fig. 2.6) to change the time of the various points in the time brackets (Fig. 2.10).




Fig. 2.10

- Press key 13 (Fig. 2.6) to confirm the change or key 14 to exit without changing the value (return to previous level).

Once the 4 schedules are set, they can be associated with the days of the week in the zones (see "Setting daily programming" on page 19).

2.6 Setting heating (Zones)

In these menus it is possible to set the various operating modes, MANUAL, AUTOMATIC and adjust the water temperature for each one.

Heating control can be set in three modes: MANUAL, AUTOMATIC and OFF.

Where:

MAN = Manual Operation

In this mode heating is enabled manually and lasts until the next and/or different setting. When the ambient temperature (if TA: Room thermostat is fitted) reaches and exceeds that set on the TA, heating switches off.

AUTO = Automatic Operation

By associating a schedule to the zone program, it is possible to set time brackets for activating space heating at a set temperature.

When the ambient temperature detected by the room thermostat is below that required, heating activates (solely if set in the schedule program).

When the ambient temperature detected by the room thermostat is above that required, space heating deactivates.

OFF = Off

Heating is always off, even if requested by the TA.




Fig. 2.11

- Press key 13 (Fig. 2.11) to access the main menu (Fig. 2.12).

INSTRUCTIONS FOR USE




Fig. 2.12




Fig. 2.15

- Press key 10 or 11 (Fig. 2.11) to select the desired menu (Fig. 2.13). "Zone 2" and "Zone 3" menus are only visible if the system is divided into zones.




Fig. 2.13

- Press key 13 (Fig. 2.11) to access the selected menu (Fig. 2.14).




Fig. 2.14

- Press key 10 or 11 (Fig. 2.11) to select the desired menu from those available (Fig. 2.15).
- Press key 13 (Fig. 2.11) again to highlight the value to be changed.
- Press key 15 or 16 (Fig. 2.11) to set the desired value.

- Press key 13 (Fig. 2.11) to confirm the change or key 14 to exit without changing the value (return to previous level).

The "Zone 1" delivery temperature can be temporarily changed by entering a manual value using keys 15 and 16 (Fig. 2.11). To return to automatic control, simply press key 12 or wait for the next change of time bracket.

To change the delivery temperature in the other zones (where present), proceed as follows:

- Press key 13 (Fig. 2.11) to access the main menu (Fig. 2.16).




Fig. 2.16

- Press key 10 or 11 (Fig. 2.11) to select the desired menu (Fig. 2.17).

INSTRUCTIONS FOR USE




Fig. 2.17

- Press key 13 (Fig. 2.11) to access the selected menu (Fig. 2.18).




Fig. 2.18

- Press key 13 (Fig. 2.11) to access the selected menu (Fig. 2.19).




Fig. 2.19

- Press key 13 (Fig. 2.11) to access the selected menu (Fig. 2.20).
- Press key 13 (Fig. 2.11) again to highlight the value to be changed.
- Press key 15 or 16 (Fig. 2.11) to set the desired value.




Fig. 2.20

- Press key 13 (Fig. 2.11) to confirm the change or key 14 to exit without changing the value (return to previous level).

2.7 Setting daily programming

In the "Zones" menu, it is possible to assign time brackets (schedules 1 to 4) to the various zones in the heating system (max 3).




Fig. 2.21

- Press key 13 (Fig. 2.21) to access the main menu (Fig. 2.22).



Fig. 2.22

- Press key 10 or 11 (Fig. 2.21) to select the

INSTRUCTIONS FOR USE

desired menu (Fig. 2.23).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 2.23

Zone 1 program (zone 2 and 3 where present)

- Press key 13 (Fig. 2.21) to access the selected menu (Fig. 2.24).

Clock and programmes	
Set date and time	[...]
Aut. daylight saving time	Yes
Schedules	[...]
Program Zone 1	[...]
DHW Program	[...]
Holiday Program	Off

Fig. 2.24

- Press key 10 or 11 (Fig. 2.21) to select the day or group of days to be set (single day, Monday - Friday, Saturday - Sunday, Monday - Saturday, Monday - Sunday) (Fig. 2.25).
- Press key 15 or 16 (Fig. 2.21) to select the desired schedule (1 to 4) (Fig. 2.25).


Program Zone 1	
Day/s	Monday
Calendar	3
	

Fig. 2.25

- Press key 13 (Fig. 2.21) to confirm the change or key 14 to exit without changing

the value (return to previous level).

Holiday Program

Boiler operation can be suspended for a certain period of time (1 to 30 days). The program starts on the day of programming and ends at midnight on the last set day.

Only anti-freeze function is guaranteed during this period.



In the event of a power failure, holiday program is cancelled.

- Press key 13 (Fig. 2.21) to access the selected menu (Fig. 2.26).

Clock and programmes	
Set date and time	[...]
Aut. daylight saving time	Yes
Schedules	[...]
Program Zone 1	[...]
DHW Program	[...]
Holiday Program	Off

Fig. 2.26

- Press key 13 (Fig. 2.21) again to highlight the value to be changed (Fig. 2.27).
- Press key 15 or 16 (Fig. 2.21) to select the desired schedule (1 to 4) (Fig. 2.27).


Clock and programmes	
Set date and time	[...]
Aut. daylight saving time	Yes
Schedules	[...]
Program Zone 1	[...]
DHW Program	[...]
Holiday Program	5gg

Fig. 2.27

- Press key 13 (Fig. 2.21) to confirm the change or key 14 to exit without changing the value (return to previous level).

INSTRUCTIONS FOR USE

2.8 Fault and anomaly signals

The display signals any anomaly by showing a number adjacent to the  symbol and the message "Fault in progress" at the bottom of the display (Fig. 2.28).




Fig. 2.28

Key 12 flashes to signal the appliance is in lockout (Fig. 2.29).



Fig. 2.29

Proceed as follows to reset the lockout anomaly:

- Press key 12 and wait 1 second.
- Press key 12 again.
- Press key 13 to reset the fault or key 14 to cancel the operation (Fig. 2.30).




Fig. 2.30



Frequent safety lockouts should be reported to an authorised service centre.

2.9 Shutdown

Press and hold key 12 (Fig. 2.31) for at least 4 seconds until the OFF symbol appears on the display (Fig. 2.32).




Fig. 2.31



Fig. 2.32

If the boiler will be inactive for a long period of time:

- Disconnect the boiler from the electric power supply;
- Close the boiler cocks Fig. 2.33.

INSTRUCTIONS FOR USE




Fig. 2.33

- If necessary, empty the hydraulic circuits see section "Emptying the C.H. system" on page 76.

2.10 Reset / User factory settings

The "User factory settings" function is used to restore all parameters set by the user to factory settings.

To do this:

- Press key 13 (Fig. 2.31) to access the main menu (Fig. 2.34).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 2.34

- Press key 10 or 11 (Fig. 2.31) to select the desired menu (Fig. 2.35).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 2.35

- Press key 13 (Fig. 2.31) to access the selected menu (Fig. 2.36).

General settings	
Language	ITA
Display	[...]
Access level	[...]
User factory settings	[...]

Fig. 2.36

- Press key 13 (Fig. 2.31) to access the selected menu (Fig. 2.37).
- Press key 13 (Fig. 2.31) again to confirm the RESET.



Only confirm the "Request for confirmation" if you are sure you want to restore all user parameters to factory settings!


Request for confirmation	
	
Confirm the operation?	

Fig. 2.37

- Press key 13 (Fig. 2.31) to confirm the

INSTRUCTIONS FOR USE

change or key 14 to exit without changing
the value (return to previous level).

USEFUL ADVICE

3 USEFUL ADVICE

3.1 Central Heating

For your comfort and added system control, you can install a room thermostat but you should not shut off the radiator in that room or have a TRV fitted on the radiator.

If a radiator (or a convector) does not heat up, check that no air is present in it and that its valve is open. If the ambient temperature is too high, do not alter the radiator valves. Reduce the central heating temperature instead by means of the room thermostat or by pressing the 15 and 16 heating adjustment keys (Fig. 3.1).




Fig. 3.1

3.2 Frost protection

The built in anti frost system protects the boiler from frost damage but does not provide any protection for the system, an optional external frost protection thermostat can be added and a dedicated connection point is available on the electrical connection block.

The anti-freeze function is also activated with the boiler in stand-by (Fig. 3.2).




Fig. 3.2

Therefore, when the boiler is not lit and used in cold weather, with consequent risk of freezing do not switch off the boiler at the fused spur isolation switch or close the gas inlet cock.

If the boiler is deactivated, have a qualified technician empty the boiler (heating circuit), the C.H. system.

3.3 Condensate drain

The condensate drain must not be modified or blocked. Blockage of the condensate drain, caused by debris or freezing, can cause automatic shutdown of the boiler. If freezing is suspected and the pipe run is accessible an attempt may be made to free the obstruction by pouring hot water over the exposed pipe and cleaning any blockage from the end of the pipe.

If this fails to remedy the problem the assistance of a Gas Safe registered installer or in IE a competent person should be sought.

3.4 Periodic maintenance

For efficient and continuous operation of the boiler, it is advisable to arrange maintenance and cleaning by an Authorised Service Centre Engineer, at least once a year. During the service, the most important components of the boiler will be inspected and cleaned. This service can be part of a maintenance contract. In particular, you are advised to have the following checks car-

USEFUL ADVICE

ried out:

- condensing heat exchanger;
- burner;
- exhaust fume duct and flue;
- pressurisation of the expansion tank;
- filling up of the central heating circuit;
- bleeding of air from the central heating system;
- general check of the appliance's operation.

Please refer to the servicing information on section "MAINTENANCE" on page 74.

3.5 External cleaning




Before carrying out any cleaning, disconnect the appliance from the electrical mains, using the fused spur isolation switch fitted adjacent to the appliance.

To clean the external panels, use a cloth soaked in soapy water. Do not use solvents, abrasive powders or sponges.

Do not carry out cleaning of the appliance and/or its parts with readily flammable substances (for example petrol, alcohols, naphtha, etc.).

3.6 Operational faults

If the boiler does not function and the LCD display shows a number and the  symbol (see "LCD general features" on page 9), the boiler is in lockout. Key 12 flashes (Fig. 3.3).




Fig. 3.3




Fig. 3.4

Proceed as follows to reset the lockout anomaly:

- Press key 12 and wait 1 second.
- Press key 12 again.
- Press key 13 to reset the fault or key 14 to cancel the operation (Fig. 3.5).





Fig. 3.5



Frequent safety lockouts should be reported to an authorised service centre.

After three reset attempts, code "91" and the  symbol (Fig. 3.6) appear on the LCD

USEFUL ADVICE

display. The boiler is in lockout mode.





Fig. 3.6

To restore boiler operation, disconnect the electrical power supply. Then, reconnect it and press keys 10, 11 and 13 (Fig. 3.3) on the boiler control panel at the same time for at least 5s.

Other operational faults signalled on the LCD display

If the LCD display displays a code and the  symbol, the boiler has an anomaly that cannot be reset (Fig. 3.7).




Fig. 3.7

! In order to reset good functioning of the boiler, call a competent and responsible Service Engineer.

Noise due to air bubbles are heard during operation

You should check that the pressure on the pressure gauge is not below the correct setting.

If required, top up the system correctly, as described in the section "Refilling procedure" on page 14 of this manual. Bleed

any air present in the radiators, if necessary.

The pressure has gone down

It is necessary to top up the appliance with water again, so as to raise the pressure to an adequate level as described in the section "Refilling procedure" on page 14 of this manual. If topping up with water has to be done very frequently, have the system checked for leaks.

Water comes out of the pressure relief valve

Check on the pressure gauge that the pressure in the central heating circuit is not close to 3 bars. In this case, temperature rise in the circuit can cause the pressure relief valve to open. So that this does not happen and to decrease the pressure to a normal value, it is advisable to vent some of the water in the appliance through the bleed valves present in the radiators.

If before water should occasionally leak from the boiler

Shut off the valves positioned under the boiler to page 21 and call an Authorised Service Centre Engineer.

! In this case or in case of problems other than those mentioned here, switch off the boiler, as described in section "Shutdown" on page 21 and call a competent and responsible Service Engineer.

3.7 Fault history

In this menu it is possible to view the last 10 faults occurring on the system (no. 1 being the most recent). In the case of a boiler malfunction, provide this information to the service centre so that they can identify the cause.

USEFUL ADVICE




Fig. 3.8

- Press key 13 (Fig. 3.8) to access the main menu (Fig. 3.9).




Fig. 3.9

- Press key 10 or 11 (Fig. 3.8) to select the desired menu (Fig. 3.10).




Fig. 3.10

- Press key 13 (Fig. 3.8) to access the selected menu (Fig. 3.11).
- Press key 13 (Fig. 3.8) again to highlight the value to be changed (Fig. 3.11).




Fig. 3.11

- Press key 13 (Fig. 3.8) again to highlight the value to be changed (Fig. 3.12).




Fig. 3.12

- Press key 13 (Fig. 3.8) again to highlight the value to be changed.
- Press key 15 or 16 (Fig. 3.8) to select the alarm history index (Fig. 3.13).




Fig. 3.13

- Press key 14 (Fig. 3.8) repeatedly to return to the previous levels.

USEFUL ADVICE

3.8 Displaying in INFO mode

The INFO mode allows the display of some information on the boiler functioning status. In case of malfunctioning of the boiler, it may be useful to communicate such information to the Authorised Service Centre Engineer so that the causes can be understood.




Fig. 3.14

- Press key 13 (Fig. 3.14) to access the main menu (Fig. 3.15).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 3.15

- Press key 10 or 11 (Fig. 3.14) to select the desired menu (Fig. 3.16).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 3.16

- Press key 13 (Fig. 3.14) to access the selected menu.
- Press key 10 or 11 (Fig. 3.14) the scroll through the list (Fig. 3.17).

Information	
Gas type	NG
Delivery temperature	19°C
DHW temperature	19°C
Set heating	85°C
Set DHW	60°C
Outdoor temperature	4°C

Fig. 3.17

- Press key 14 (Fig. 3.14) repeatedly to return to the previous levels.

The table summarises the possible values visible in INFO mode.

Menu Item	Description
Type of gas	Displays gas type: NG (0:Methane), LG (1:L.P.G.)
Delivery temperature	Displays delivery temperature
DHW temperature	Displays D.H.W. output temperature
Set heating	Displays set heating temperature
DHW set	Displays set D.H.W. temperature
Outdoor temperature	Displays outdoor temperature if external sensor fitted (optional)
DHW input temperature	Displays D.H.W. input temperature
Return temperature	Displays return temperature
Delivery temperature 2	Displays safety delivery probe

USEFUL ADVICE

Menu Item	Description
System delivery temp.	Displays the temperature read by the system delivery probe (optional)
Pump flow rate	Displays system flow rate
DHW flow rate	Displays the D.H.W. flow rate measured by the flow meter
Fan speed	Displays fan speed (rpm)
Flue gas temperature	Displays flue gases temperature
Maintenance within	Displays the number of days within which maintenance must be carried out (*)
Main board. SW rev.	Displays boiler board SW version
Firmware version	Displays display board SW version

(*) The row is not displayed after the number of days or if the function is deactivated.

3.9 Remote anomaly code

If the boiler is connected to remote (optional), a code that indicates a boiler anomaly is displayed in the centre of the display.

The anomaly in progress is indicated by a numeric code followed by the letter **E**.

The anomaly codes sent to the remote are the same as those shown on the display (see "SIGNAL DISPLAYED BY THE LCD" on pag. 10).

3.10 Flue probe and safety thermal fuse



If the flue thermal cut-off fuse is triggered, the boiler goes into safety lockout. To restore nor-

mal boiler operation, please contact an Authorized Service Centre.

The flue probe and safety thermal fuse 24 indicated in Fig. 3.18 are a safety device. The flue probe 24 intervenes when the flue temperature exceeds 110°C placing the boiler in safety block switching it off.

To reset normal boiler functioning, just press the 12 (Fig. 3.14) key.

If flue probe 24 does not intervene and, therefore does not send the boiler into security lockout, flue thermal fuse 24 is triggered as an additional safety device to protect the flue outlet pipe.

To restore the normal operation of the boiler, contact the Authorized Service Centre.




Fig. 3.18

TECHNICAL INFORMATION

4 TECHNICAL INFORMATION

4.1 Overview




Fig. 4.1

4.2 Main diagram




Fig. 4.2

- | | | | |
|----|--|----|--|
| 3 | Condensate drain pipe | 25 | C.H. temperature return probe NTC |
| 4 | C.H. flow valve | 26 | Condensing heat exchanger |
| 5 | Gas inlet valve | 27 | NTC heating delivery probe - NTC maximum temperature |
| 6 | C.H. pressure relief valve pipe | 28 | Flame-detecting electrode/ignition electrode |
| 7 | Main circuit drain valve | 29 | C.H. pressure relief valve |
| 8 | C.H. return valve | 30 | Automatic air purger valve |
| 24 | Flue temperature probe NTC and Safety thermal fuse | | |

TECHNICAL INFORMATION

- 31 Pump
- 32 Gas valve inlet test point
- 33 Gas valve
- 34 Gas valve outlet test point
- 35 Primary circuit pressure transducer
- 36 Condensate trap
- 37 Fan
- 38 Air/gas mixer
- 39 Burner
- 40 C.H. expansion tank
- 41 Flue outlet pipe
- 42 Air intake pipe
- 43 Flue exhaust sampling point
- 44 Air sampling point
- 45 By-pass valve

TECHNICAL INFORMATION

4.3 Hydraulic specifications

The hydraulic specifications represents the pressure (available head for the central heating system) as a function of the flow rate.

Model **ANTARES 30S (M300V.30 SR)**

Pressure (bar)




Fig. 4.3

The boiler load loss has already been removed.

Flow rate with closed thermostatic valves

The boiler is equipped with an automatic by-pass, which protects the condensing primary exchanger.

In case of excessive reduction or total stopping of water circulation in the heating system due to the closing of thermostatic valves or circuit elements valves, the by-pass ensures a minimum water circulation inside the condensing primary exchanger.

The by-pass is calibrated to a differential pressure of about 0.3-0.4 bar.

4.4 Expansion vessel

Note: this boiler is designed for operation only in a sealed central heating system.

The height difference between the pressure relief valve and the highest point in the system may be 10 m at most.

For greater differences, increase the pre-load pressure in the expansion vessel and the system, when cold, by 0.1 bar for each additional 1 m.

Total capacity	l	8,0
Pre-load pressure	kPa	100
	bar	1.0
Useful capacity	l	4.0
Maximum volume of water in the system *	l	125

Fig. 4.4

* Where conditions are:

- Average maximum temperature of the system is 85 °C
- Initial temperature when filling up the system is 10 °C



For systems with volumes greater then the one indicated in the above table, an additional expansion vessel must be provided.

TECHNICAL INFORMATION

4.5 Technical data ANTARES 30S (M300V.30 SR)

Heat input		
Nominal net ^(A)	kW	31,0
	BTU/h	105776
Nominal net ^(A) with 20% H2NG mixture	kW	28,4
	BTU/h	96905
Nominal gross ^(B)	kW	34,4
	BTU/h	117412
Nominal net ^(A)	kW	3,8
	BTU/h	12966
Minimum gross ^(B)	kW	4,2
	BTU/h	14392

Useful output		
Maximum	kW	30,6
	BTU/h	104411
Minimum	kW	3,6
	BTU/h	12284
Maximum condensing	kW	33,6
	BTU/h	114648
Minimum condensing	kW	4,0
	BTU/h	13649

Central heating		
Min/Max flow temperature settings*	°C	25 - 80
Maximum pressure	kPa	250
	bar	2,5
Minimum pressure	kPa	30
	bar	0,3
Available head (in 1000 l/h)	kPa	54,0
	bar	0,54

* to the minimum useful output

^(A) referred to the net calorific value at 15 °C and 1013,25 mbar: G20 = 34,02 MJ/m³ - G31 = 46,34 MJ/kg

^(B) referred to the gross calorific value at 15 °C and 1013,25 mbar: G20 = 37,78 MJ/m³ - G31 = 50,37 MJ/kg

Gas supply pressures			
Gas		Pa	mbar
Natural G20	Nom	2000	20
	Min	1700	17
	Max	2500	25
Propane G31	Nom	3700	37
	Min	2500	25
	Max	4500	45

Gas rate maximum		
Natural G20	m ³ /h	3,28
Propane G31	kg/h	2,41
Gas rate minimum		
Natural G20	m ³ /h	0,40
Propane G31	kg/h	0,30

Electrical data		
Voltage	V~	230
Frequency	Hz	50
Nominal Power consumption	W	116
Minimum Power consumption	W	11
Stand-by Power consumption	W	3
Protection degree		IPX5D
External fuse rating	A	3
Internal fuse rating	A	N° 2 - 2 AF

TECHNICAL INFORMATION

Flue design		
Boiler type		
B23P C13 C33 C43 C53 C63 C83 C93		
Ø Coaxial	mm	60/100
Ø Twin split pipes	mm	80/80
Ø Roof	mm	60/100
Ø Roof	mm	80/125
Nominal heat flow rate ^{(A) (E)}	kW	n.a.
Exhaust temperature ^(E)	°C	78,0
Mass flow rate ^(E)	kg/s	0,0209

Flue gas figures		
Nominal heat input ^{(A) (E)}	kW	n.a.
CO ₂ content with gas G20	%	n.a.
O ₂ content with gas G20	%	4,8
CO content with gas G20	ppm	200,0
Exhaust temperature ^(E)	°C	78,0
NO _x class		6
Weighted NO _x	ppm	16

^(E) Values refer tests with a 1 m flue working at the nominal heat input

CO ₂ contents		
Nominal heat input ^{(A) (E)}	kW	31,0
CO ₂ content with gas G20 (range min - max)	%	8,5 - 9,5
CO ₂ content with gas G31 (range min - max)	%	9,6 - 10,6
Minimum heat input ^{(A) (E)}	kW	3,8
CO ₂ content with gas G20 (range min - max)	%	8,5 - 9,5
CO ₂ content with gas G31 (range min - max)	%	9,5 - 10,5

Other specifications		
Height	mm	700
Width	mm	400
Depth	mm	300
Weight (dry)	kg	36,0
Water volume in the boiler (up to 1 bar)	l (kg)	2,5

(2978)

TECHNICAL INFORMATION

Model(s):	ANTARES 30S		M300V.30 SR
Condensing boiler:			Yes
Low-temperature boiler (**):			No
B1 boiler:			No
Cogeneration space heater:	No	If yes, equipped with a supplementary heater:	-
Combination heater:			No

Item	Symbol	Value	Unit	Item	Symbol	Value	Unit
Rated heat output	P_{rated}	31	kW	Seasonal space heating energy efficiency	η_s	94	%
				Seasonal energy efficiency class		A	
For boiler space heaters and boiler combination heaters: Useful heat output				For boiler space heaters and boiler combination heaters: Useful efficiency			
At rated heat output and high-temperature regime (*)	P_4	30,6	kW	At rated heat output and high-temperature regime (*)	η_4	89,0	%
At 30% of rated heat output and low-temperature regime (**)	P_1	10,2	kW	At 30% of rated heat output and low-temperature regime (**)	η_1	99,0	%
Auxiliary electricity consumption				Other items			
At full load	el_{max}	0,052	kW	Standby heat loss	P_{siby}	0,110	kW
At part load	el_{min}	0,011	kW	Ignition burner power consumption	P_{ign}	-	kW
In standby mode	P_{SB}	0,003	kW	Annual energy consumption	Q_{HE}	94	GJ
				Sound power level, indoors	L_{WA}	50	dB
				Emission of nitrogen oxides	NO_x	28	mg/kWh

For combination heaters:

Declared load profile				Water heating energy efficiency	η_{wh}		%
Daily electricity consumption	Q_{elec}		kWh	Daily fuel consumption	Q_{fuel}		kWh
Annual electricity consumption	AEC		kWh	Annual fuel consumption	AFC		GJ
Contact details	See manual cover						

(*) High-temperature regime means 60°C return temperature at heater inlet and 80°C feed temperature at heater outlet.

(**) Low temperature means for condensing boilers 30°C, for low-temperature boilers 37°C and for other heaters 50°C return temperature (at heater inlet).

GENERAL REQUIREMENTS

5 GENERAL REQUIREMENTS



Benchmark places responsibilities on both manufacturers and installers. The purpose is to ensure that customers are provided with the correct equipment for their needs, that it is installed, commissioned and serviced in accordance with the manufacturer's instructions by competent persons and that it meets the requirements of the appropriate Building Regulations. The Benchmark Checklist can be used to demonstrate compliance with Building Regulations and should be provided to the customer for future reference.

Installers are required to carry out installation, commissioning and servicing work in accordance with the Benchmark Code of Practice which is available from the Heating and Hotwater Industry Council who manage and promote the Scheme. Visit www.hhic.co.uk for more information.

Our Company supports the Benchmark initiative. The Benchmark Checklist is located at the back of this manual and should be completed by the Installing/Commissioning Gas Safe Registered Engineer and handed over to the User for future reference by other visiting Engineers. Also included is the Service Interval Record card that should be completed by the Service Engineer following the annual service maintenance of the boiler and system.

For Ireland (IE), it is necessary to complete a "Declaration of Conformity" to indicate compliance to I.S.813.2002.

This appliance must be installed by a competent person in accordance with the Gas Safe (installation & Use) Regulations.

5.1 Related documents

The installation of this appliance must be in accordance with the relevant requirements of the current Gas Safe (Installation & Use) Regulations, the Local Building Regulations, the current I.E.E. Wiring Regulations, the Regulations and by-laws of the local water undertaking, and in Scotland, in accordance with the Building Standards (Scotland) Regulation. Health and safety document n° 635 "Electricity at work regs."

It should also be in accordance with the British Standard Codes of Practice:

In Ireland (IE). The installation must be carried out by a Competent Person and registered with the RGII and installed in accordance with the current edition of I.S.813.2002 "Domestic Gas Installations" the current Building Regulations and reference should be made to the current ETCI rules for electrical installations.

5.2 Location of appliance

The appliance may be installed in any room or internal space, although particular attention is drawn to the requirements of the current I.E.E. Wiring Regulations, and in Scotland, the electrical provisions of the Building Regulations applicable in Scotland, with respect to the installation of the appliance in a room containing a bath or shower.

For Ireland (IE), reference should be made to the current edition of I.S.813.2002 and the current ETCI rules for electrical installations.

Where a room-sealed appliance is installed in a room containing a bath or shower, any electrical switch or appliance control, utilising mains electricity should be so situated that it cannot be touched by a person using the bath or shower.

The location must permit the provision of an adequate flue and termination.

For unusual locations special procedures may be necessary and BS 6798 gives detailed

GENERAL REQUIREMENTS

guidance on this aspect.

A compartment used to enclose the appliance must be designed specifically for this purpose. This appliance is not suitable for external installation.

5.3 Flue system

The provision for satisfactory flue termination must be made as described in BS 5440 part 1.

For Ireland (IE), refer to I.S.813.2002.

The appliance must be installed so that the flue terminal is exposed to external air.

It must not be installed so that the terminal discharges into another room or space as an outhouse or lean-to. It is important that the position of the terminal allows a free passage of air across at all times.

The terminal should be located with due regard for the damage or discoloration that might occur to building products in the vicinity.

In cold and/or humid weather water vapour may condense on leaving the flue terminal; the effect of such "steaming" must be considered.

Plumbing may easily occur at the terminal. Where possible, terminal position which could cause a nuisance should be avoided.

The minimum acceptable spacing from the terminal to obstructions and ventilation openings are specified in Fig. 5.1.




Fig. 5.1

GENERAL REQUIREMENTS

Symbol	Location position	Minimum dimensions (mm)
A *	Directly below an opening, air brick, opening window, etc.	300
B *	Above an opening, air brick, opening window, etc.	300
C *	Horizontally to an opening, air brick, opening window, etc.	300
D **	Below temperature-sensitive building components, e.g. plastic gutter soil pipes or drain pipes	75
E **	Below eaves	200
F	Below balconies	200
G	From a vertical drain pipe or soil pipe	150
H ***	From an internal or external corner	300
I	Above ground, roof or balcony level	300
J	From a surface facing a terminal	600
K	From a terminal facing a terminal	1 200
L	From an opening in the car-port (e.g. door, window) into the dwelling	Not recommended
M	Vertically from a terminal on the same wall	1 500
N	Horizontally from a terminal on the same wall	300
O	From the wall on which the terminal is mounted	Please refer to the flue assembly instructions
P	From a vertical structure on the roof	600
Q	Above intersection with the roof	600
R	From a roof window and terminal	600
S	From a roof window and terminal	2 500

* In addition, for temperature and structural reasons, the terminal should not be near than 150 mm to an opening in the building fabric formed for the purpose of accommodating a built-in element such as a sealed window frame.

** A heat protection shield should also be installed.

*** The reference to external corners does not apply to building protrusions not exceeding 450 mm, such as disused chimneys on external walls.

5.4 Gas supply

The Gas meter is connected to the service pipe by the local gas region or a local gas region contractor.

If the gas supply for the boiler serves other appliances ensure that an adequate supply is available both to the boiler and the other appliance when they are in use at the same time.

Pipework must be of adequate size. Pipes of a smaller size than the boiler inlet connection should not be used.

Installation pipes should be fitted in accordance with BS 6891 and the complete installation should be tested for tightness.

For Ireland (IE), refer to I.S.813.2002.

GENERAL REQUIREMENTS

5.5 Air supply

The room in which the boiler is installed does not require a purpose provided air vent.

5.6 Ventilation

If installed in a cupboard or compartment, it is not necessary to provide additional ventilation for cooling for this particular product. However consideration must be given to clearance requirements for maintenance (section "Precautions for installation" on page 43) and under no circumstances must stored articles be allowed to come into contact with the boiler or flue pipe.

5.7 Condensate drain

Ensure that the condensate discharge complies with the national or local regulations in force.

The condensate pipe must be fitted in accordance with Building Regulations.

Drain pipe material should be resistant to acid as the condensate is slightly acid with a pH less than 6.5.

The boiler includes a trap (36 on page 30) that prevents the combustion products entering the drain.

The boilers incorporate a condensate trap with a 225 mm seal to comply with BS 6798: 2008. The schematic diagrams of possible connections are given in Fig. 5.2 and Fig. 5.3.

The length of the condensate pipe should be kept to a minimum, any external pipe should not be more than 3 m in 32 mm pipe and insulated to prevent freezing.

To avoid condensate being trapped:

- the drain pipe should be run with a fall of at least 2.5° (45 mm/m) away from the boiler;
- the number of bends and joints should be kept at minimum;
- the drain pipe should be adequately fixed to prevent pipe sagging.

If a part of the drainpipe runs externally this part should be kept as short as possible and protected to reduce the risk of freezing.

Connection of condensate drainage pipe to internal soil and vent stack.




Fig. 5.2

- A Boiler
- B Internal soil and vent stack
- C Invert
- D 450 mm up to three storeys

Connection of condensate drainage pipe downstream of a sink waste trap




Fig. 5.3

- A Boiler
- E Sink
- F Open end of condensate drainage pipe direct into gully below grating but above water level

Combined condensate and PRV discharge

It is possible to combine the PRV and condensate discharge pipes providing the following precautions are followed explicitly.

GENERAL REQUIREMENTS

- A WRAS approved dry trap such as the Tesla DTUN 1522 is utilised.
- That the condensate is connected downstream of the trap as shown in the drawing and no copper pipe is utilised below this point.
- That the 32 mm equal T and subsequent downstream connection waist pipe is HT certified and capable of handling the potential short term expected temperature such as HDPE or polypropylene, consideration should also be given to the type of stack and its material in the event of the PRV activating.

At all times during design and component selection a worst case scenario event should be considered e.g. a short term exposure of high flow at high temperature along with normal running conditions of the corrosive nature of the condensate.

Connection combined condensate and PRV discharge.




Fig. 5.4

- A** Boiler
- G** 15 mm copper PRV discharge pipe work
- H** WRAS approved dry trap such as the Tesla DTUN1522
- I** 22 mm copper PRV discharge pipe work
- J** 21.5 mm solvent condensate discharge pipe work
- K** High temperature rated equal 32 mm T with required adapters for condensate and PRV inlets
- L** High temperature rated Waist discharge pipe work with a minimum diameter of 32 mm

5.8 Water circulation (C.H.)

Detailed recommendations are given in BS 6798, BSEN 12828: 2003, BSEN 12831: 2003 & BSEN 14446: 2004; the following notes are given for general guidance.

For Ireland (IE), refer to I.S.813.2002.

Pipework

Copper tubing to BSEN 1057 is recommended for water pipes. Jointing should be either with capillary soldered or with compression fittings. Where possible pipes should have a gradient to ensure air is carried naturally to air release points and water flows naturally to drain taps. The appliance has a built-in automatic air release valve, it should be ensured as far as possible that the appliance heat exchanger is not a natural collecting point for air.

Except where providing useful heat, pipes should be insulated to prevent heat loss and to avoid freezing.

Particular attention should be paid to pipes passing through ventilated spaces in roofs and under floors.

By-pass

The appliance includes an automatic by-pass valve which protects the main heat exchanger in case of reduced or interrupted water circulation through the heating system due to the closing of thermostatic valves or isolation valves within the system.

The by-pass is calibrated to assure a minimum flow of 200-300 lts/hr through the main heat exchanger.

If you are installing a system that includes thermostatic radiator valves (TRV) and/or small bore (8-10 mm) it may be necessary to fit an external by-pass to facilitate correct operation of the boiler.

The fitting of an external bypass helps to prevent and limit system noise.

Air release points

These must be fitted at all high points where air will natural collect and must be sited to

GENERAL REQUIREMENTS

facilitate complete filling of the system.

Expansion vessel

The appliance has an integral sealed expansion vessel to accommodate the increase of water volume when the system is heated.

Refer to Fig. 4.4 on page 33 for its technical data.

If the heating circuit has an unusually high water content, calculate the total expansion and add an additional sealed expansion vessel with adequate capacity.

Mains water feed: central heating

There must be no direct connection to the mains water supply even through a non return valve, without the approval of the Local Water Authority.

Filling

A method for initially filling the system and replacing water lost during servicing must be provided and it must comply with local water authority regulations.

The correct method is shown in Fig. 5.5.

The temporary connection must be removed immediately after filling.




Fig. 5.5

The installer should ensure that no leaks exist either inside the boiler or on the system as frequent filling of the system could cause premature scaling of the heat exchanger.

5.9 Water treatment

C.H. circuit

Where a new boiler is fitted to a new system

with either plastic or copper pipes, it is important the system is fully flushed, on completion, to ensure flux residues, swarf, oils and other installation debris is removed.

Where a new boiler is fitted to an existing system, it is important the debris from the existing system is fully removed in order to ensure the efficiency of the new appliance is maintained. Details on flushing procedure are given in the section "Initial filling of the system" on page 54 of this manual.

5.10 Electrical supply

Warning, this appliance must be earthed.

External wiring to the appliance must be carried out by a competent person and be in accordance with the current I.E.E. Regulations and any local regulations which apply.

Reference should be made to the current ETCI rules for electrical installations.

For Ireland (IE), refer to I.S.813.2002.

The boiler is supplied for connection to a 230 V~ 50 Hz supply.



The mains supply to this appliance must be protected with a 3A mains fuse, under no circumstance should this fuse rating be exceeded.

The method of connection to the electricity supply must facilitate complete electrical isolation of the appliance by the use of a fused spur isolation switch. Its installation permits a complete switching off in the conditions of the overvoltage category III. Alternatively it can be connected with a 3A fused three pin plug and unswitched shuttered socket outlet both complying with BS 1363.

The point of connection to the electricity supply must be readily accessible and adjacent to the appliance, except where the appliance is installed in a bathroom, this must then be sited outside the bathroom.

6 INSTALLATION

6.1 Warnings



The use of gas appliances is subject to statutory control; it is essential to observe the current regulations and laws in force (see also chapter 5).

The appliance must discharge combustion products directly outside or into a suitable exhaust duct designed for this purpose. Combustion products must be discharged using original flue kits only, since they are integral parts of the boiler.

The appliance is not suitable for receiving condensate coming from the combustion products evacuation system.



Combustion air must avoid contents of chlorine, ammonia, or alkali agents. Installation of a boiler near a swimming pool, a washing machine, or a laundry does expose combustion air to these aggressive contents”.

Before installing the boiler on an existing C.H. system, flush it out thoroughly before fitting the boiler.

This procedure is to remove the presence of any residues or impurities that could compromise good functioning of the boiler.

After flushing it is necessary to treat the system.

The conventional warranty does not cover any problems deriving from failure to comply with such provisions.

For Propane, the appliance must also conform with the requirements of the distributors and comply with current Regulations and laws in force.

The safety relief valve and the condensate drain must be connected to a suitable drain, or discharged in a safe manner.

The electrical wiring must conform with current Regulations, in particular:

- the boiler must be earthed using the correct bonding clamp.
- a fused spur isolation switch, must be installed near to the boiler that allows complete isolation in category III over voltage conditions.

Refer to section "Electric connection" on page 49 in this chapter for the electrical connections.

Under no circumstances will the manufacturer be held responsible if the warnings and instructions contained in this manual have not been complied with.


6.2 Precautions for installation



The following prescriptions must be respected for installation:

- The boiler must be fixed to a strong wall.
- The dimensions for the flue system (detailed in section "Choice of flue" on page 46) and the correct procedures for installing the flue, depicted in the instruction leaflet included with the flue kit, must be complied with during installation.
- To allow maintenance procedures it is necessary to leave the minimum clearances indicated in Fig. 6.1.

INSTALLATION



All measurements are in mm

Fig. 6.1

system chemicals are used, this will ensure that no unwanted chemical reactions take place as system chemical manufacturers ensure own brand compatibility,

6.3 Installing the bracket

Precautions

Before mounting the bracket, check that the dimensions for fitting the flue system are complied with (refer to the leaflet included with the flue kit, packed separately).

Utilise the paper template supplied with the boiler to determine the fixing position for the bracket and boiler. Securely mount the bracket to the wall using appropriate fixings suitable for the type of wall construction and capable of supporting the total (wet) load. Refer to the weight given in the technical data tables specific for each model.

- When installing the boiler in a cupboard, cover or alcove allow at least 5 mm permanent clearance from the front face of the boiler. Also ensure sufficient clearance to allow free access for servicing.
- Before installing the boiler on an existing C.H. system, flush it out thoroughly before fitting the boiler, so as to remove system debris.

It is advisable to equip the system with a quality magnetic system filter, you should also use a water-treatment product in the circulating water.

The latter option in particular, has an anti-corrosive effect by promoting formation of a protective skin on metal surfaces and neutralising gases present in the water.

We recommend the use of a suitable Build-cert approved universal inhibitor to protect the C.H. system from corrosion.

Biasi UK strongly recommend that matched

INSTALLATION

6.4 Overall dimensions

The boiler respects the following dimensions:




Fig. 6.2

- A** Flue outlet / air intake pipe (co-axial $\varnothing 100/60$)
- B** Flue outlet pipe $\varnothing 80$ mm (twin kit)
- C** Air intake pipe $\varnothing 80$ mm (twin kit)
- D** Bracket
- E** Electric connections area
- F** Condensate drain connection area
- G** C.H. flow
- H** Gas
- I** C.H. return

6.5 Joints

The boiler uses the following fittings:

Functions	Pipe sizes (o.d)
Gas, C.H. return, C.H. flow	$\varnothing 22$ mm
Pressure relief valve	$\varnothing 15$ mm
Condensate drain	$\varnothing 20$ mm (rubber)
<i>sizes in mm o.d.</i>	

Condensate drained with $\varnothing 21.5$ mm solvent weld pipe

6.6 Mounting the boiler

- Take the protective caps off the boiler pipework.
- Thoroughly clean the connections.
- Fix the C.H. valves "K" to position "G" and "I" (Fig. 6.2) using the $\frac{3}{4}$ " gaskets.
- Fix the gas cock "L" to position "H" (Fig. 6.2), using the $\frac{3}{4}$ " gasket.
- Fix the $\varnothing 22$ mm copper pipes "J" to the valves "K – L" using the $\frac{3}{4}$ " gaskets.




Fig. 6.3

- Connect the pipe 6 (Fig. 6.4) from the pressure relief valve to the safety discharge pipework.
- Fit the condensate drain 3 (Fig. 6.4) in to the drainage pipework.
- See also section "Condensate drain" on page 40 in this manual.

INSTALLATION




Fig. 6.4

6.7 Fitting the flue system

For a correct installation of the flue pipe, refer to the sheet provided together with the pre-selected kit.

The horizontal run of the flue pipes must incline about 1.5 degrees (25 mm per meter); therefore the terminal must be higher than the intake at the boiler.

The standard horizontal flue kit must be fitted horizontal as the inner flue exhaust pipe is already angled with the correct incline.

CORRECT system for installing the wall flue




Fig. 6.5

A = air intake
S = flue exhaust

6.8 Choice of flue

The flue exhaust/air intake can be installed in the mode:

C13 C33 C53 C63



The terminal must be higher than the boiler.

The following kits to be connected to the boiler are available:

Wall flue exhaust kit (Fig. 6.6 A)

This kit allows the flues to be exhausted in the rear wall or at the side of the boiler.

Coaxial pipe Ø 60/100 (A)	
Nominal length	0.915 m
Minimum length	0.5 m
Maximum length	10 m

Type C13




Fig. 6.6

Vertical flue exhaust kit with 90° bend (Fig. 6.6 B)

This kit allows the boiler exhaust axis to be lifted by 635 mm.

The terminal must always exhaust horizontally.

INSTALLATION

Coaxial pipe Ø 60/100 with 90° bend (B)	
Nominal length	1.55 m
Minimum length	0.5 m
Maximum length	10 m

Additional bends at 45° or 90° (Fig. 6.6 C)

Coaxial bends Ø 60/100 mm.

These bends when used with the pipe reduce the maximum length of the flue pipe by:

For the bend of 45° loss	0.5 m
For the bend of 90° loss	1 m

Exhaust intake split pipes kit Ø 80 mm - (Fig. 6.7) - (Fig. 6.8)

This kit allows the flue exhaust to be separated from the air intake.

Split pipes kit Ø 80 mm	
Minimum length	0.5 m
Maximum length (a + b)	40 m

N.B: The air intake and the flue outlet must not terminate on opposite sides of the building (EN 483).

Type C₁₃




Fig. 6.7

Bends of Ø 80 mm at 90° and at 45° are available that reduce the maximum total length of the pipes by:

For the bend of 45° loss	0.9 m
For the bend of 90° loss	1.65 m

Type C₅₃




Fig. 6.8

Roof flue exhaust kit (Fig. 6.9)

This kit exhausts directly to the roof.

Coaxial pipe Ø 60/100 mm	
Nominal height	0.96 m
Maximum height	10 m

Coaxial pipe Ø 80/125 mm		
Nominal height		0.96 m
Maximum height	30 kW	15 m

Type C₃₃




Fig. 6.9

Extensions are available for reaching the maximum height.

Bends at 90° and at 45° are available that reduce the maximum total length of the

INSTALLATION

pipes by:

For the bend of 45° loss	0.5 m
For the bend of 90° loss	1 m

Plumbing kit A (Fig. 6.10)

Coaxial Ø 60/100 mm + vertical part Ø 60 mm (flue outlet).

Coaxial Ø 60/100 mm (b) + vertical part Ø 60 mm (a)	
Telescopic coaxial flue	0.45-0.95 m
Maximum length (a + b)	15 m

This kit allows the products of combustion to be discharged at a different location to the air intake to avoid nuisance issues.




Fig. 6.10

60 mm elbows and extensions can be added to the vertical section.

Each additional elbow reduces the overall acceptable length of the flue system as follows:

For the bend of 45° (60/100 mm) loss	0.5 m
For the bend of 90° (60/100 mm) loss	1 m
For the bend of 45° (60 mm) loss	0.65 m
For the bend of 90° (60 mm) loss	0.85 m

Plumbing kit B (Fig. 6.11) (Fig. 6.12)

Push on type Ø 60 mm vertical plume management kit

This kit allows the products of combustion to be discharged at a different location, when used with the standard horizontal flue kit.




Fig. 6.11

Each additional elbow reduces the overall acceptable length of the flue system as follows:

For the bend of 45° (60/100 mm) loss	0.5 m
For the bend of 90° (60/100 mm) loss	1 m
For the bend of 45° (60 mm) loss	0.65 m
For the bend of 90° (60 mm) loss	0.85 m

The chart Fig. 6.12 gives the maximum allowed value for **a + b** of (Fig. 6.11).

INSTALLATION




Fig. 6.12

A Plume deflector is available to assist in overcoming boundary nuisance issues.




Fig. 6.13

6.9 Electric connection

- Unscrew screws "M" and remove the front panel "N" by pulling it and pushing it towards the top so that it is freed from the top housing Fig. 6.14 and Fig. 6.15.




Fig. 6.14




Fig. 6.15

- Unscrew the screw "O" (Fig. 6.16).




Fig. 6.16

- Turn the control panel "P", as shown in Fig. 6.17.
- Unscrew the screw "Q" and lift the cover "R" to access the electric power supply

INSTALLATION

terminal block, remote and external sensor (Fig. 6.17).




Fig. 6.17

Electric power supply connection

- Connect the electric power supply cable coming from the fused spur isolation switch to the power supply terminal block of the boiler Fig. 6.18 keeping the same connections for the live (brown wire) and the neutral (blue wire). External 3A fuse or fused plug with same current rating is recommended.
- **Connect the earth cable (yellow/green) to an effective earth plant.**




Fig. 6.18



The earth cable must be the longest of the electric power supply cables.

The appliance's electric power supply cable or wire must have a section no less than 0.75 mm², it must be kept away from hot or sharp parts and however conform to the technical regulations in force.

Allow the cables to exit the boiler by using the relevant cable clamps "S" (Fig. 6.19).




Fig. 6.19

INSTALLATION

6.10 Connecting the room thermostat or zone valves

Use the clamps indicated in Fig. 6.18 to connect the ambient thermostat.

Remove the electric jumper present between "1 and 2" when connecting any type of ambient thermostat.

The electric cables of the ambient thermostat are inserted between clamps "1 and 2" as in Fig. 6.20.



Do not connect live wires to terminals to which the room thermostat must be connected.

Voltage-free contacts for
the Ambient Thermostat or External
Remote Control sensor




Fig. 6.20

The thermostat must be insulation class II (□) or must be correctly connected to earth.

Allow the cables to exit the boiler by using the relevant cable clamps "S" (Fig. 6.19).

Connecting the zone valves controlled by the ambient thermostat




Fig. 6.21

Use the ambient thermostat's clamps indicated in Fig. 6.20 to connect the zone valve. Insert the electric cables of the zone valve's micro switch contacts in clamps "1 and 2" of the ambient thermostat's terminal block as in Fig. 6.20.

Remove the electric jumper between "1 and 2".

Allow the cables to exit the boiler by using the relevant cable clamps "S" (Fig. 6.19).

6.11 Installation of the external temperature probe (optional)

The external probe must be installed on the external wall of the building avoiding:

- Direct sunlight.
- Humid walls or walls subject to the formation of mildew.
- Installation near to fans, drain outlets or chimneys.
- It is recommended to be installed on a north aspect wall at least 1 m below any

INSTALLATION

eaves and at least 2 m above ground.

6.12 Electric connection between the boiler and the external probe

To connect the external probe to the boiler use electric cables with a section no less than 0.50 mm².

The electric cables for connecting the external probe to the boiler must cover different channels to the voltage ones (230 V), since they are powered at a safety low voltage and their maximum length must not exceed 20 meters.

Use the clamps indicated in Fig. 6.22 to connect the external probe.




Fig. 6.22

Allow the cables to exit the boiler by using the relevant cable clamps "S" (Fig. 6.19).

6.13 Remote electric connection (optional)

Use the clamps indicated in Fig. 6.22 to connect the remote.

To connect the remote control to the boiler, refer also to the REMOTE CONTROL booklet.

Do not remove the electric jumper connected on the ambient thermostat terminal block between "1 and 2" Fig. 6.22.

Allow the cables to exit the boiler by using the relevant cable clamps "S" (Fig. 6.19).

6.14 Example of hydraulic systems with hydraulic separator (optional)

The hydraulic separator creates a reduced load loss zone that renders the primary circuit and secondary circuit hydraulically independent.

In this case the flow rate that passes through the circuits depends exclusively on the features of the pumps flow rate.

Therefore, by means of a hydraulic separator, the secondary circuit's flow rate is put into circulation only when the relative pump is on.

When the pump of the secondary is off, there is no circulation in the corresponding circuit and therefore, the entire flow rate pushed by the primary is by-passed through the separator.

Thus, with the hydraulic separator, it is possible to have a constant flow rate production circuit and a variable flow rate distribution circuit.

INSTALLATION

Hydraulic system examples

Top zone + low temperature zone.




Fig. 6.23

Top zone + 2 low temperature zones.




Fig. 6.24

COMMISSIONING

7 COMMISSIONING

7.1 Warnings

The commissioning of this boiler and system must only be undertaken by a Gas Safe Registered Engineer in accordance with the requirements of the Gas Safe Installation and Use Regulations and be approved by Gas Safe.

Ensure that the Benchmark Checklist is satisfactorily completed during the commissioning process. The Checklist is located at the end of this manual. This manual should be handed to the user following completion of the installation and commissioning process. Failure to comply with these requirements may invalidate the manufacturers guarantee.

For Ireland (IE), it is necessary to complete a "Declaration of Conformity" to indicate compliance to I.S.813.2002.

7.2 Electrical installation

Preliminary electrical system checks to ensure electrical safety shall be carried out by a competent person. i.e. polarity, earth continuity, resistance to earth and short circuit.

If a fault has occurred on the appliance the fault finding procedure should be followed as specified in the service manual.

7.3 Gas supply installation

- Inspect the entire installation including the gas meter, test for tightness and purge, all as described in BS 6891;
For Ireland (IE), refer to I.S.813.2002.
- Open the gas cock 5 (Fig. 7.1) on the appliance and check the gas connector on the appliance for leaks.




Fig. 7.1

7.4 Initial filling of the system

- Open the C.H. flow and return valves.
- Remove the front and side panels of the case (section "Dismantling the external panels" on page 75) and the sealed chamber lid.
- Loosen the cap on the automatic air purger valve 30 in Fig. 7.2 and leave open permanently.




Fig. 7.2

COMMISSIONING

- Gradually open stopcock at the filling point connection to the C.H. system until water is heard to flow; do not open fully.
- Open each radiator air vent starting at the lowest point of the system and close it only when clear water, free of bubbles, flows out.
- Continue filling the system. The actual reading should ideally be 1,3 bar and not less than 0,3 bar.
- Close all air release valves on the C.H. system.
- Inspect the boiler and the system for water tightness and remedy any leaks discovered.
- Cold flush the system to remove any loose particles and any system debris before starting the boiler for the first time.

Check pump operation/pump release

The pump electronic control circuit automatically releases the pump.

The flushing procedure must be in line with BS7593:2006 Treatment of Water in D.H.W. & C.H. Systems.


When the installation and second filling are completed turn on the C.H. system and run it until the temperature has reached the boiler operating temperature. The system must then be immediately flushed through. This procedure must be repeated twice more.

During this operation a C.H. flushing detergent must be used in the quantities as specified by the appropriate manufacturer, whose function it is to dissolve any foreign matter which may be in the system.

INHIBITION (Primary Heating Circuit)

On the final refilling of the heating system it is important to ensure the system water is treated with a suitable scale and corrosion inhibitor in accordance with the manufacturers instructions.

Only inhibitors that carry the Buildcert approved label should be used.

- Electrically power the boiler by activating the installed bipolar switch. The LCD display shows the  symbol (boiler in Stand-by) (Fig. 7.3).




Fig. 7.3




Fig. 7.4

- Press key 12 (Fig. 7.4) repeatedly and select the desired mode (see Fig. 7.5).



Fig. 7.5



If the boiler is OFF, key 12 (Fig. 7.4) must be held down for at least 4 seconds to reactivate it.

- Open the gas cock.
- Make sure that the ambient thermostat is in the "heat request" position.

COMMISSIONING

- Check the correct operation of the boiler.
- Check the gas pressures and flow rates as shown in section "GAS CONVERSION" on page 72 of this booklet.
- Check that the condensate produced during functioning fills the syphon and is regularly drained in the draining pipe.

Automatic air venting function



The C.H. functions are not active during this period.

Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.

- Press key 13 (Fig. 7.4) to go to the main menu (Fig. 7.6).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 7.6

- Press key 10 or 11 (Fig. 7.4) to select the desired menu (Fig. 7.7).

Menu	
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]
Assistance	[...]

Fig. 7.7

- Press key 13 (Fig. 7.4) to access the selected menu (Fig. 7.8).

Assistance	
Boiler	[...]
DHW	[...]
Heating	[...]
Inputs	[...]
Special functions	[...]
Maintenance	[...]

Fig. 7.8

- Press key 10 or 11 (Fig. 7.4) to select the desired menu from those available (Fig. 7.9).
- Press key 13 (Fig. 7.4) again to highlight the value to be changed.

Special functions	
Deaeration	[...]
Chimney sweep function	[...]
Calibration complete	[...]
Fast calibration	[...]

Fig. 7.9

- Press key 13 (Fig. 7.4) to access the selected menu (Fig. 7.10).

Deaeration	
Vent enabled	⬆ No

Fig. 7.10

- Using key 15 or 16 it is possible to set the automatic air vent function to run each time the appliance is switched on (Fig. 7.11).

COMMISSIONING

VALUE	DESCRIPTION
No	Function disabled (default).
Once	Forced once only on switching on the appliance.
All	Forced each time the appliance is switched on.

Fig. 7.11

- Press key 13 (Fig. 7.4) to confirm the change or key 14 to exit without changing the value (return to previous level).
- Turn off the boiler and press key 12 (Fig. 7.4) for 5 seconds until the LCD display indicates the symbol (I).
- Show the user how to use the appliance correctly and also explain:
 - ignition;
 - shut off;
 - making adjustments.

The user is responsible for keeping the documentation together and intact, and within reach for consultation.

7.5 Condensate pipe and traps

The full length of the condensate pipe should be checked for leaks.

Before running the boiler, ensure that the built in condensate trap and any other trap in the drain system is correctly filled with water.



Fill the built in condensate trap by removing the flue elbow and pouring a cupful of water into the flue outlet (Fig. 7.12).

Warning do not allow water to enter the outer air intake




Fig. 7.12

An alternative, to the removal of the flue elbow, pour the water through the flue sampling point (Fig. 7.13).




Fig. 7.13

7.6 Checking the gas supply pressure

This boiler has been factory tested to the highest quality control standards and set for the minimum and maximum gas working pressures, connected to a 1 m flue and a gas supply pressure of 20 mbar.

Any variation in gas supply pressure or flue length may result in the customer experiencing a harmonic noise from the boiler. In these circumstances, it may be necessary to reset the burner gas pressures in accordance with section 11 Gas Valve of the Service Manual.

It should be noted that a Flue Gas Analyser is required for this procedure.

7.7 Checking the inlet pressure

- Remove the boiler front panel, see section "Dismantling the external panels" on page

COMMISSIONING

75.

- With the boiler switched on at full rate (maximum output power), check the supply pressure by using the 32 point in Fig. 7.14 and compare the value with that reported on the Gas supply pressure table (minimum inlet pressure) in section "Technical data ANTARES 30S (M300V.30 SR)" on pag. 34.
- Ensure the test nipple 32 in Fig. 7.14 is firmly closed.




Fig. 7.14

If it does not comply with the required pressure check the gas supply line and governor for faults and/or correct adjustment.

Where the boiler is connected to a gas supply which has a zero set governor then it is necessary under the Gas Safe (Installation and Use) Regulations 26.9. to perform a combustion analysis test for CO/CO₂ (The limits for the boiler is given in section "Technical data ANTARES 30S (M300V.30 SR)" on pag. 34: CO₂ contents / other flue gas figures) and complete the Certificate of Exemption section of the Benchmark.

Important: after the checks all of the test

points must be sealed and tested for tightness.

7.8 Lighting the boiler

Some products incorporate an anti cycling time delay. It is normal when first switching the boiler on for the boiler to operate on heating for a few seconds then switch off. After 3-4 minutes has elapsed the boiler will then re-ignite and operate perfectly normally.

If external controls are fitted (e.g. Timeclock, room thermostat) ensure they "call for heat".

- Electrically power the boiler by switching on the double pole isolation switch. The LCD will display the boiler status (Fig. 7.15 or Fig. 7.16).




Fig. 7.15





Fig. 7.16

- Press the 12 key for 5 seconds until the boiler temperature and  symbol appear on the display Fig. 7.18.




COMMISSIONING




Fig. 7.17



Fig. 7.18

- Open the gas cock.
- Make sure that the ambient thermostat is in the "heat request" position".
- Check the correct functioning of the boiler.
- Check the gas pressures and flow rates as shown in section "GAS CONVERSION" on page 72 of this booklet.
- Check that the condensate produced during operation fills the syphon and is regularly drained in the draining pipe.
- Switch off the boiler by pressing the 12 (Fig. 7.17) key for 5 seconds until the  symbol appears on the LCD display (Fig. 7.15).
- Press the 12 key for 5 seconds until  symbol appear on the display Fig. 7.17. The LCD display displays the boiler temperature (primary circuit) and the  symbol Fig. 7.18.

The boiler will now go through an ignition sequence and the burner will light.
If after four ignition attempts (about four min-

utes) the boiler does not function and a code adjacent to the  symbol and the message "Fault in progress" at the bottom of the display (Fig. 7.19). Key 12 (Fig. 7.17) flashes to signal the appliance is in lockout.




Fig. 7.19

Proceed as follows to reset the lockout anomaly:

- Press key 12 and wait 1 second.
- Press key 12 again.
- Press key 13 to reset the fault or key 14 to cancel the operation (Fig. 7.20).




Fig. 7.20


For the first lighting up and following maintenance procedures for the gas supply, it may be necessary to repeat the resetting operation several times so as to remove the air present in the pipework.

After five consecutive resetting attempts the reset key is inhibited. To restore its function it is necessary to switch the boiler off and on from the electrical mains, using the fused spur isolation switch fitted adjacent to the appliance.

COMMISSIONING

7.9 Checking the ignition device

With the burner on high flame close the gas cock.

After four ignition attempts (about four minutes) the boiler does not function and a code adjacent to the  symbol and the message "Fault in progress" at the bottom of the display (Fig. 7.21). Key 12 (Fig. 7.17) flashes to signal the appliance is in lockout.




Fig. 7.21

Proceed as follows to reset the lockout anomaly:

- Press key 12 and wait 1 second.
- Press key 12 again.
- Press key 13 to reset the fault or key 14 to cancel the operation (Fig. 7.22).




Fig. 7.22

7.10 Checking the flue system

The flue system should be visually checked for soundness. Check all clamps, gaskets and fixing are secure and tight.

Ensure that the flue terminal is sited correctly in accordance with the flue fitting instructions and Fig. 5.1 on page 38 of this manual.

To carry out a combustion check refer to the instructions given in the section "Combustion

analysis check" on page 78 of this manual.

Reference figures are given in section "Technical data ANTARES 30S (M300V.30 SR)" on pag. 34 (Flue gas figures).

7.11 Checking the condensate drain pipe

Check the soundness and integrity of the condensate drain pipe.

Verify the cleanness and correct filling of the condensate traps.

7.12 Instructing the user

Hand over this combined User & Installation manual and the Service manual to the end user and explain how to use the unit.

Take the User step by step through the lighting instructions.

Show the User how to switch off the appliance quickly and indicate the position of the electric supply isolator.

Explain the proper use and adjustment of all system controls; this will ensure the greatest possible fuel economy.

Explain the function and use of the function selector.

Explain and demonstrate the function of time and temperature controls (if fitted).

Explain how to turn off the appliance for both short and long periods and advise on the precautions necessary to prevent damage should the appliance be inoperative when freezing conditions may occur.

Fill in the details required on the Boiler Guarantee Certificate and hand to the User advising them to return the correct section for boiler Guarantee registration.

Finally, advise the User that, for continued safe and efficient operation, the appliance must be serviced by a competent person at least once a year.

The user is responsible for keeping the documentation integral and within reach for consultation.

ADVANCED COMMISSIONING

8 ADVANCED COMMISSIONING

8.1 Accessing the "Service" menu (Installer)

! Access restricted to authorised and appropriately trained technicians.

To access the "Service" menu, restricted to authorised and appropriately trained technicians, proceed as follows:



Fig. 8.1

- Press key 13 (Fig. 8.1) to access the main menu (Fig. 8.2).




Fig. 8.2

- Press key 10 or 11 (Fig. 8.1) to select the desired menu (Fig. 8.3).




Fig. 8.3

- Press key 13 (Fig. 8.1) to access the selected menu (Fig. 8.4).




Fig. 8.4

- Press key 13 (Fig. 8.1) again and enter the password (6683). Use key 15 or 16 to enter the corresponding value and key 10 or 11 to move to the next value. Press key 13 again to confirm the password (Fig. 8.5).




Fig. 8.5

- Press key 15 or 16 (Fig. 8.1) to select "Service" (Fig. 8.6).

ADVANCED COMMISSIONING




Fig. 8.6

- Press key 13 (Fig. 8.1) again to confirm access to the "Service" level or key 14 to exit (return to previous level).

! "Service" level remains active while browsing the menus and for 4 more minutes after returning to the main screen.

! If the appliance is switched off and back on, the menu automatically returns to User level.

8.2 Selecting the type of external sensor

The boiler is set to operate without an external sensor.

If an external sensor (optional) is connected to the boiler, the correct parameter must be set according to the type of probe installed.

Sequence for setting the type of external sensor

Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.




Fig. 8.7

- Press key 13 (Fig. 8.7) to go to the main menu (Fig. 8.8).




Fig. 8.8

- Press key 10 or 11 (Fig. 8.7) to select the desired menu (Fig. 8.9).




Fig. 8.9

- Press key 13 (Fig. 8.7) to access the selected menu (Fig. 8.10).




Fig. 8.10

- Press key 10 or 11 (Fig. 8.7) to select the desired menu from those available (Fig. 8.11).
- Press key 13 (Fig. 8.7) again to highlight the value to be changed.




Fig. 8.11

- Use key 15 or 16 to modify the value of the parameter according to the type of probe installed (Fig. 8.12).

VALUE	DESCRIPTION
0	Sensor not present (factory settings)
1	beta 3760 - External sensor with 12 kOhm NTC
2	beta 3435 - External sensor with 10 kOhm NTC

Fig. 8.12

- Press key 13 (Fig. 8.7) to confirm the change or key 14 to exit without changing the value (return to previous level).

8.3 Enabling operation with the external sensor and setting the K coefficient of the external temperature probe

The K coefficient is a parameter that increases or decreases the boiler delivery temperature as the outdoor temperature varies.

The boiler is set with a K coefficient of zero for operation without the probe connected. If an external sensor (optional) is connected to the boiler, the correct parameter must be set according to the type of probe installed (see "Selecting the type of external sensor" on page 62) and the K coefficient must be set based on the efficiency of the heating system to optimise the delivery temperature (Fig. 8.13).

Delivery temperature °C




Fig. 8.13

E.g. To achieve a heating system delivery temperature of 60°C with an outdoor temperature of -5°C, set a K of 1.5 (dashed line in Fig. 8.13).

Sequence for setting the K coefficient

Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.

ADVANCED COMMISSIONING




Fig. 8.14

- Press key 13 (Fig. 8.14) to go to the main menu (Fig. 8.15).




Fig. 8.15

- Press key 10 or 11 (Fig. 8.14) to select the desired menu (Fig. 8.16).




Fig. 8.16

- Press key 13 (Fig. 8.14) to access the selected menu (Fig. 8.17).




Fig. 8.17

- Press key 10 or 11 (Fig. 8.14) to select the desired menu from those available (Fig. 8.18).
- Press key 13 (Fig. 8.14) to access the selected menu.




Fig. 8.18

- Press key 13 (Fig. 8.14) again to access the selected menu.




Fig. 8.19

- Press key 10 or 11 (Fig. 8.14) to select the desired menu from those available (Fig. 8.20).
- Press key 13 (Fig. 8.14) again to highlight the value to be changed.

ADVANCED COMMISSIONING

Zone 1 - Adjustment	
Modul. with ext. sensor	Yes
Offset climatic curve	0°C
Reduced	Off
Max. external temp.	25°C
Min. external temp.	-5°C
Set delivery maximum	60°C

Fig. 8.20

- Use key 15 or 16 to modify the value of the selected parameter, referring to the curves in Fig. 8.13.
- See Fig. 8.21 for the parameters to be modified.

PARAMETER	VALUE DEFAULT
Max. external temp.	25 °C
Min. external temp.	-5 °C
Set delivery maximum	60 °C
Set delivery minimum	30 °C

Fig. 8.21

- Press key 13 (Fig. 8.14) to confirm the change or key 14 to exit without changing the value (return to previous level).

The system delivery temperature will follow the trend in relation to the set K coefficient.

If the room temperature is not comfortable, increase or decrease the heating system delivery temperature by $\pm 15^{\circ}\text{C}$ using the 15 (decrease) and 16 (increase) keys (Fig. 8.14).

8.4 Selecting minimum/maximum heating temperature

Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.




Fig. 8.22

- Press key 13 (Fig. 8.22) to go to the main menu (Fig. 8.23).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 8.23

- Press key 10 or 11 (Fig. 8.22) to select the desired menu (Fig. 8.24).

Menu	
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]
Assistance	[...]

Fig. 8.24

- Press key 13 (Fig. 8.22) to access the selected menu (Fig. 8.25).

ADVANCED COMMISSIONING




Fig. 8.25

- Press key 10 or 11 (Fig. 8.22) to select the desired menu from those available (Fig. 8.26).
- Press key 13 (Fig. 8.22) again to highlight the value to be changed.




Fig. 8.26

- Use key 15 or 16 to modify the value of the parameter according to the type of system (Fig. 8.27).

Heating set min			
Sets the heating set minimum limit			
Default	Min	Max	Unit
25	25	45	degrees
Heating set max			
Sets the heating set maximum limit			
Default	Min	Max	Unit
80	45	85	degrees

Fig. 8.27

- Press key 13 (Fig. 8.22) to confirm the change or key 14 to exit without changing the value (return to previous level).

8.5 Setting pump post-circulation

The pump, in heating mode, is set for a post-circulation of about one minute at the end of each heat request.

This time can be changed from a minimum of 10 seconds to a maximum of 20 minutes in programming mode, using either the control panel or the remote.

Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.




Fig. 8.28

- Press key 13 (Fig. 8.28) to go to the main menu (Fig. 8.29).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 8.29

- Press key 10 or 11 (Fig. 8.28) to select the desired menu (Fig. 8.30).

ADVANCED COMMISSIONING




Fig. 8.30

- Press key 13 (Fig. 8.28) to access the selected menu (Fig. 8.31).




Fig. 8.31

- Press key 10 or 11 (Fig. 8.28) to select the desired menu from those available (Fig. 8.32).
- Press key 13 (Fig. 8.28) again to highlight the value to be changed.




Fig. 8.32

- Press key 10 or 11 (Fig. 8.28) to select the desired menu (Fig. 8.33).




Fig. 8.33

- Use key 15 or 16 to modify the value of the selected parameter.
- Press key 13 (Fig. 8.28) to confirm the change or key 14 to exit without changing the value (return to previous level).

8.6 Selecting the reignition frequency

When the boiler functions in normal on/off heating mode, the minimum time between two ignitions is set to 6 minutes (re-ignition frequency).

This time can be changed from a minimum of 1 to a maximum of 120 minutes by programming it either from the control panel or remotely.

Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.




Fig. 8.34

ADVANCED COMMISSIONING

- Press key 13 (Fig. 8.34) to go to the main menu (Fig. 8.35).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 8.35

- Press key 10 or 11 (Fig. 8.34) to select the desired menu (Fig. 8.36).

Menu	
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]
Assistance	[...]

Fig. 8.36

- Press key 13 (Fig. 8.34) to access the selected menu (Fig. 8.37).

Assistance	
Boiler	[...]
DHW	[...]
Heating	[...]
Inputs	[...]
Special functions	[...]
Maintenance	[...]

Fig. 8.37

- Press key 10 or 11 (Fig. 8.34) to select the desired menu from those available (Fig. 8.39).
- Press key 13 (Fig. 8.34) again to highlight the value to be changed.

Boiler	
External relays	[...]
Flue system	[...]
Timers	[...]
Anti-freeze function	[...]
Pump	[...]
Factory settings	[...]

Fig. 8.38

- Press key 10 or 11 (Fig. 8.34) to select the desired menu (Fig. 8.39).

Timers	
Heating anti-cycling	6
Heating post-circulation	0
Heating ramp	0

Fig. 8.39

- Use key 15 or 16 to modify the value of the selected parameter.
- Press key 13 (Fig. 8.34) to confirm the change or key 14 to exit without changing the value (return to previous level).

8.7 Reset / "Service" factory settings (installer)

The "Service factory settings" function is used to restore all parameters set by the installer to factory settings.

To do this:

Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.

ADVANCED COMMISSIONING




Fig. 8.40

- Press key 13 (Fig. 8.40) to go to the main menu (Fig. 8.41).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 8.41

- Press key 10 or 11 (Fig. 8.40) to select the desired menu (Fig. 8.42).

Menu	
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]
Assistance	[...]

Fig. 8.42

- Press key 13 (Fig. 8.40) to access the selected menu (Fig. 8.43).

Assistance	
Boiler	[...]
DHW	[...]
Heating	[...]
Inputs	[...]
Special functions	[...]
Maintenance	[...]

Fig. 8.43

- Press key 10 or 11 (Fig. 8.40) to select the desired menu (Fig. 8.44).
- Press key 13 (Fig. 8.40) again to highlight the value to be changed.

Boiler	
External relays	[...]
Flue system	[...]
Timers	[...]
Anti-freeze function	[...]
Pump	[...]
Factory settings	[...]

Fig. 8.44

- Press key 13 (Fig. 8.40) to access the selected menu (Fig. 8.45).

General settings	
Language	ITA
Display	[...]
Access level	[...]
User factory settings	[...]
Service factory settings	[...]

Fig. 8.45

- Press key 13 (Fig. 8.40) to access the selected menu (Fig. 8.46).
- Press key 13 (Fig. 8.40) again to confirm the RESET.

ADVANCED COMMISSIONING



Only confirm the "Request for confirmation" if you are sure you want to restore all user parameters to factory settings!




Fig. 8.46

- Press key 13 (Fig. 8.40) to confirm the change or key 14 to exit without changing the value (return to previous level).

8.8 Boiler adjustment record

For information on replacing and configuring the control board, please contact an authorised service centre.

Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.




Fig. 8.47

- Press key 13 (Fig. 8.47) to go to the main menu (Fig. 8.48).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 8.48

- Press key 10 or 11 (Fig. 8.47) to select the desired menu.
- Press key 13 (Fig. 8.47) to access the selected menu.
- Use key 15 or 16 (Fig. 8.47) to change the value of the parameter.
- Press key 13 (Fig. 8.47) to confirm the change or key 14 to exit without changing the value (return to previous level).
- Set the following parameters:

ADVANCED COMMISSIONING

PARAMETER	MENU ITEM	MODEL	VALUE
P59	Menu > General settings > Language		ITA
			ENG
			POL
			SPA
			HU
P01	Menu > Assistance > Boiler > Combustion > Model	ANTARES 30S (M300V.30 SR)	15
P02	Menu > Assistance > Boiler > Combustion > Gas type		NG (CH4)
			LG (G31)
P04	Menu > Assistance > Boiler > Hydraulic		Stor. tank
P05	Menu > Assistance > Inputs > Configurable input		transduc.2
P06	Menu > Assistance > DHW > Storage tank control input		No
P09	Menu > Assistance > Boiler > Power > CH max power	ANTARES 30S (M300V.30 SR)	90
P11	Menu > Assistance > Boiler > Pump > Minimum speed		70
P13	Menu > Assistance > Boiler > Pump > Mode		2
P40	Menu > General settings > Display > Display current value		CH
P47	Menu > Assistance > Special functions > De-aeration function > Vent enabled		1
P48	Menu > Assistance > Boiler > Pump > CH maximum speed		100
P49	Menu > Assistance > Boiler > Pump > DHW maximum speed		100
P58	Menu > General settings > Display > Brand		Biasi
P61	Menu > Assistance > Boiler > Primary flow rate min. set		32
P62	Menu > Assistance > Boiler > Flue system > Flue gas offset		15

To exit the parameters menu:

- wait 15 minutes without pressing any key;
- switch off the electric power supply.

For calibration, see the instructions given in the Service manual, section Gas valve - Automatic calibration of the gas valve.

GAS CONVERSION

9 GAS CONVERSION

9.1 Warnings

The commissioning of this boiler and system must only be undertaken by a Gas Safe Registered Engineer, qualified to work on Liquefied Petroleum Gas (LPG) in accordance with the requirements of the Gas Safe Installation and Use Regulations.

Components used to adapt it to the type of gas available must be genuine parts only.

Factory setting = Natural gas.

9.2 Operations and gas setting



Check that the gas cock mounted on the gas piping to the boiler is closed and that the appliance is not powered.

Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.




Fig. 9.1

- Press key 13 (Fig. 9.1) to go to the main menu (Fig. 9.2).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 9.2

- Press key 10 or 11 (Fig. 9.1) to select the desired menu (Fig. 9.3).

Menu	
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]
Assistance	[...]

Fig. 9.3

- Press key 13 (Fig. 9.1) to access the selected menu (Fig. 9.4).

Assistance	
Boiler	[...]
DHW	[...]
Heating	[...]
Inputs	[...]
Special functions	[...]
Maintenance	[...]

Fig. 9.4

- Press key 10 or 11 (Fig. 9.1) to select the desired menu from those available (Fig. 9.5).
- Press key 13 (Fig. 9.1) again to highlight the value to be changed.

GAS CONVERSION

Boiler	
Hydraulic	Mixed
Set primary pres. min	1.0bar
Noise reduction	Off
Combustion	[...]
Power	[...]
External relays	[...]

Fig. 9.5

- Press key 13 (Fig. 9.1) again to highlight the value to be changed.

Combustion	
Model	[...]
Gas type	[...]
Fan rpm min	[...]
Fan rpm max	[...]
Fan rpm acc.	[...]
Factory settings	[...]

Fig. 9.6

- Use key 15 or 16 to set the type of gas (Fig. 9.7).

VALUE	DESCRIPTION
NG	Operation with Methane gas (G20) (default).
LG	Operation with LPG (G31).

Fig. 9.7

- Press key 13 (Fig. 9.1) to confirm the change or key 14 to exit without changing the value (return to previous level).
- Apply the label indicating the type of gas and the pressure value for which the unit is set. The self-adhesive label is contained in the documentation envelope attached to the boiler.
- For calibration, see the instructions given in the Service manual, section Gas valve - Automatic calibration of the gas valve.

! "Warning if during any PCB re programming you disengage the power supply to the boiler you may corrupt the software setup, ensure you wait at least 10 seconds after any re programming before any power isolation event takes place".

10 MAINTENANCE

10.1 Warnings

The procedures detailed in this chapter **must be carried out only by a Gas Safe Registered Engineer**. Thus you are advised to contact an Authorised Service Agent.

For Ireland (IE), the servicing work must be carried out by a competent RGII registered Person.

For efficient and continuous operation of the boiler you are advised to have, at least once a year, maintenance and cleaning done by an Approved Service Engineer.

Isolate the appliance from the electricity supply by turning off the fused spur isolation switch adjacent to the appliance.

Turn off the gas cock, before carrying out any procedures, whatsoever, for cleaning, maintenance, opening or dismantling boiler panels.



Other devices i.e. external controls may lead dangerous voltage inside the appliance as well. Ensure they are isolated. In case of doubt turn off the general system switch.

The Engineer should complete the Service Interval Record at the back of the manual.

10.2 Programming the maintenance period

Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.




Fig. 10.1

- Press key 13 (Fig. 10.1) to go to the main menu (Fig. 10.2).




Fig. 10.2

- Press key 10 or 11 (Fig. 10.1) to select the desired menu (Fig. 10.3).




Fig. 10.3

- Press key 13 (Fig. 10.1) to access the selected menu (Fig. 10.4).

MAINTENANCE

Assistance	
Boiler	[...]
DHW	[...]
Heating	[...]
Inputs	[...]
Special functions	[...]
Maintenance	[...]

Fig. 10.4

- Press key 10 or 11 (Fig. 10.1) to select the desired menu from those available (Fig. 10.5).
- Press key 13 (Fig. 10.1) again to highlight the value to be changed.

Maintenance	
Select number of months	Off

Fig. 10.5

- Use key 15 or 16 to set the number of months until the next maintenance date (Fig. 10.6).

Select number of months			
Setting for the number of months until scheduled maintenance			
Default	Min	Max	Unit
Off	Off	36	months

Fig. 10.6

- Press key 13 (Fig. 10.1) to confirm the change or key 14 to exit without changing the value (return to previous level).

10.3 Dismantling the external panels

Front panel

- Unscrew the screws "A" and remove the

front panel "D" by pulling it towards you and then pushing it upwards in order to free it from the upper seats (Fig. 10.7 and Fig. 10.8).

Side panels

Loosen the screws "B", "C", "G" and "H" in Fig. 10.7 and remove the two side panels "E" and "F" push them outwards.




Fig. 10.7




Fig. 10.8

MAINTENANCE

Control panel

Remove screws "I" and turn the control panel "J", as shown in figure Fig. 10.9, for optimal access to the internal components of the boiler.




Fig. 10.9

10.4 Reassembly the external panels

Side panels

Fit the external panels "E" and "F" in the reverse order to that described on section "Dismantling the external panels" on page 75.

Front panel

- Fit the front panel "D" in the reverse order to that described on section "Dismantling the external panels" on page 75.

10.5 Emptying the C.H. system

- Close the C.H. isolating valves (4 and 8 in Fig. 10.10).




Fig. 10.10

- Loosen the central heating drain cock 7 indicated in Fig. 10.11.




Fig. 10.11

- To make draining easier, lift the plug 30 of the automatic relief valve in Fig. 10.12.




Fig. 10.12

10.6 Cleaning the condensing primary exchanger and the burner

Removing the fan burner unit 39 in Fig. 10.13.




Fig. 10.13

- Remove the front panel and lower the controls panel (see "Dismantling the external panels" on page 75).
- Disconnect the wiring of the ignition and detection electrodes.
- Unscrew the connector "K" and remove the pipe "L".
- Disconnect the connector "M" by pulling it downwards (Fig. 10.13).
- Disconnect the fan connector "N" by pulling it downwards (Fig. 10.13).
- Unscrew screws "O" and remove the fan burner unit 39 (Fig. 10.13).
- Extract the burner casing by pulling it outwards.
- The silicon seal on the front wall of the combustion chamber Fig. 10.14 must be replaced if worn.




Fig. 10.14

- The detection electrode "P" in Fig. 10.14 also functions as a sensor for the correct drainage of the condensate. Should the mentioned electrode come into contact with the condensate water present within the combustion chamber it sends the boiler into safety lockout. Therefore, should the insulation be wet or deteriorated, provide for the substitution of the same.

MAINTENANCE



Electrodes disclaimer.

Note to service engineers: It is required that the burner seal, lip seal and mixing chamber seal along with the flame detection electrode are inspected every year and replaced every 24 months. Failure to inspect the flame detection probe, seals and replace as required may render the guarantee void.

Caution: After any periodical servicing or disturbance the combustion chamber silicon seal Fig. 10.14 must be fully inspected and replaced at the discretion of the service engineer.

After any disturbance to the chamber door seal the appliance must undergo a full analytical combustion performance check.




Fig. 10.15

If the condensate primary exchanger elements are dirty (notable only after removing the burner body), brush them using a bristle brush and remove the dirt using a suction device.

The burner does not require any particular maintenance, just remove dust using a bristle brush.

More specific maintenance will be valued and carried out by a competent Gas Safe Registered Engineer.



Attention, to reassemble repeat the operations carried out in reverse order. Be careful not to damage the OR gasket of the gas pipe when inserting the pipe in Air box.

After any service operation on the components of the gas circuit check all the connections for gas leaks.

10.7 Check the pressure of the heating expansion vessel

Drain the heating circuit as described in section "Emptying the C.H. system" on page 76 and check that the expansion vessel pressure is not less than 1 bar. If the pressure is less, see to correct pressurisation.

10.8 Checking the flue system

Have the integrity of the flue outlet and air intake pipe, checked periodically, at least once a year. For all the above maintenance operations it is advisable to call an approved Service Engineer.

10.9 Combustion analysis check

It is compulsory to conduct a combustion analysis. Remove the plug as indicated in Fig. 10.16 and carry out combustion analysis check and adjustment if necessary as described in the section "Gas valve - Adjustment - Chimney Sweep Mode" of the Service manual.




Fig. 10.16

- Make sure that the ambient thermostat is in the position "call for heat".
- Activate the "flue sweep function" at maximum heating power (see "Setting the boiler flue sweep function" on page 80).
- Check the combustion of the boiler using the outlets located on the flue tubes (Fig. 10.16) and compare the data measured with that following.

Model ANTARES 30S - M300V.30 SR			
Nominal heat input ^{(A) (E)}	kW	31,0	
Nominal efficiency	%	98,8	
Combustion efficiency	%	99	
Air index	n	1,7	
Flue gas CO ₂ content	%	8,5 - 9,5	
Flue gas O ₂ content	%	4,8	
Flue gas CO content	ppm	200	
Flue gas temperature	°C	78,0	

Values refer to tests with a an 80 mm double exhaust split by 1 + 1 m and natural gas G20 and a supply / return heating temperature of 60°/80°C.

Fig. 10.17

The values in the tables are measured at the nominal useful power with factory calibration.

10.10 Checking the condensate drain pipe

The condensate drain pipe 36 (Fig. 10.18) does not require any particular maintenance but just check:

- That no solid deposits have formed, if so remove them.
- That the condensate drain piping is not clogged.

To clean the inside of the siphon, remove it and turn it upside down to remove any dirt.




Fig. 10.18

10.11 Visual inspection of appliance

Visually inspect all water joints, seals and connections for any evidence of leakage and retighten, grease or replace them as necessary.

10.12 Checking the gas supply pressure

Check appliance for gas tightness. Re-check operational pressures as described in section "Checking the gas supply pressure" on page 57 of this manual.

MAINTENANCE

10.13 Water inhibitor concentration

Where chemical products are used the level of water treatment should be checked on an annual basis and re treated after full or partial drain down.

A conductivity meter can be used to check the correct concentration of inhibitor in the heating water.

10.14 Setting the boiler flue sweep function

With the boiler set to chimney sweep mode, some automatic boiler functions can be disabled, which makes checking and monitoring operations easier.

- Go to the "Service" area following the procedure described in paragraph "Accessing the "Service" menu (Installer)" on pag. 61.



Fig. 10.19

- Press key 13 (Fig. 10.19) to go to the main menu (Fig. 10.20).

Menu	
Clock and programmes	[...]
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]

Fig. 10.20

- Press key 10 or 11 (Fig. 10.19) to select the desired menu (Fig. 10.21).

Menu	
Information	[...]
Fault history	[...]
General settings	[...]
DHW settings	[...]
Zones	[...]
Assistance	[...]

Fig. 10.21

- Press key 13 (Fig. 10.19) to access the selected menu (Fig. 10.22).

Assistance	
Boiler	[...]
DHW	[...]
Heating	[...]
Inputs	[...]
Special functions	[...]
Maintenance	[...]

Fig. 10.22

- Press key 10 or 11 (Fig. 10.19) to select the desired menu from those available (Fig. 10.23).
- Press key 13 (Fig. 10.19) again to highlight the value to be changed.

Special functions	
Deaeration	[...]
Chimney sweep function	[...]
Calibration complete	[...]
Fast calibration	[...]

Fig. 10.23

- Press key 10 or 11 (Fig. 10.19) to select the desired menu from those available (Fig. 10.24).
- Press key 13 (Fig. 10.19) again to high-

MAINTENANCE

light the value to be changed.

Chimney sweep function	
Chimney sweep fun.active	--
CH max power	100%
CH min power	0%
DHW max power	100%
DHW min power	0%
Fan speed	0prm

Fig. 10.24

To exit the parameters menu:

- wait 15 minutes without pressing any key;
- switch off the electric power supply;
- set "Chimney sweep fun.active" = 0 (Fig. 10.24) (return to previous level).

- Use key 15 or 16 to modify the value of the parameter according to the type of check to be run (Fig. 10.25).

Chimney sweep fun.active			
Activates the chimney sweep function, where: 0 = Off, 1 = D.H.W. minimum output, 2 = C.H. minimum output, 3 = C.H. maximum output, 4 = D.H.W. maximum output			
Default	Min	Max	Unit
0	0	4	coefficient

Fig. 10.25

- Press key 13 (Fig. 10.19) to confirm the change or key 14 to exit without changing the value (return to previous level).

Benchmark Commissioning & Warranty Validation Service Record

It is a requirement that the boiler is installed and commissioned to the manufacturers' instructions and the data fields on the commissioning checklist completed in full.

To instigate the boiler warranty the boiler needs to be registered with the manufacturer within one month of the installation. The warranty rests with the end-user (consumer), and they should be made aware it is ultimately their responsibility to register with the manufacturer, within the allotted time period.

It is essential that the boiler is serviced in line with the manufacturers' recommendations, at least annually. This must be carried out by a competent Gas Safe registered engineer. The service details should be recorded on the Benchmark Service and Interim Boiler Work Record and left with the householder. Failure to comply with the manufacturers' servicing instructions and requirements will invalidate the warranty.



www.hhic.co.uk

This Commissioning Checklist is to be completed in full by the competent person who commissioned the boiler as a means of demonstrating compliance with the appropriate Building Regulations and then handed to the customer to keep for future reference.

Failure to install and commission according to the manufacturers' instructions and complete this Benchmark Commissioning Checklist will invalidate the warranty. This does not affect the customer's statutory rights.

* All installations in England and Wales must be notified to Local Authority Building Control (LABC) either directly or through a Competent Persons Scheme. A Building Regulations Compliance Certificate will then be issued to the customer.

GAS BOILER SYSTEM COMMISSIONING CHECKLIST & WARRANTY VALIDATION RECORD																																					
Address:																																					
Boiler make and model:																																					
Boiler serial number:																																					
Commissioned by (PRINT NAME):														Gas Safe registration number:																							
Company name:														Telephone number:																							
Company email:														Company address:																							
																						Commissioning date:															
Heating and hot water system complies with the appropriate Building Regulations?																										Yes											
Optional: Building Regulations Notification Number (if applicable):																																					
Time, temperature control and boiler interlock provided for central heating and hot water																										Yes											
Boiler Plus requirements (tick the appropriate box(s))																																					
Boiler Plus option chosen for combination boiler in ENGLAND														Weather compensation		Smart thermostat with automation and optimisation																					
														Load compensation		Flue Gas Heat Recovery																					
Time and temperature control to hot water				Cylinder thermostat and programmer/timer														Combination boiler																			
Zone valves				pre-existing								Fitted				Not required																					
Thermostatic radiator valves				pre-existing								Fitted				Not required																					
Automatic bypass to system				pre-existing								Fitted				Not required																					
Underfloor heating				pre-existing								Fitted				Not required																					
Water quality																																					
The system has been flushed, cleaned and a suitable inhibitor applied upon final fill, in accordance with BS7593 and boiler manufacturers' instructions																										Yes											
What system cleaner was used?														Brand:							Product:																
What inhibitor was used?														Brand:							Product:																
Primary water system filter				pre-existing								Fitted								Not required																	
CENTRAL HEATING MODE measure and record (as appropriate)																																					
Gas rate (for combination boilers complete DHW mode gas rate)														m³/hr				or				ft³/hr															
Central heating output left at factory settings?														Yes								No															
If no, what is the maximum central heating output selected?																												kW									
Dynamic gas inlet pressure																												mbar									
Central heating flow temperature																												°C									
Central heating return temperature																												°C									
System correctly balanced/rebalanced?																												Yes									
COMBINATION BOILERS ONLY																																					
Is the installation in a hard water area (above 200ppm)?														Yes								No															
Water scale reducer/softener				pre-existing								Fitted								Not required																	
What type of scale reducer/softener has been fitted?														Brand:							Product:																
Water meter fitted?														Yes								No															
If yes- DHW expansion vessel				pre-existing								Fitted								Not required																	
Pressure reducing valve				pre-existing								Fitted								Not required																	
DOMESTIC HOT WATER MODE Measure and record																																					
Gas rate														m³/hr				or				ft³/hr															
Dynamic gas inlet pressure at maximum rate																												mbar									
Cold water inlet temperature																												°C									
Hot water has been checked at all outlets														Yes								Temperature															
CONDENSATE DISPOSAL																																					
The condensate drain has been installed in accordance with the manufacturers' instructions and/or BS5546/BS6798																										Yes											
Point of termination														Internal								External (only where internal termination impractical)															
Method of disposal														Gravity								Pumped															
ALL INSTALLATIONS																																					
Record the following		At max rate:		CO		ppm		CO ₂		%		CO/CO ₂		Ratio																							
		At min rate (where possible)		CO		ppm		CO ₂		%		CO/CO ₂		Ratio																							
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?																										Yes											
The operation of the boiler and system controls have been demonstrated to and understood by the customer																										Yes											
The manufacturers' literature, including Benchmark Checklist and Service Record, has been explained and left with the customer																										Yes											
Commissioning Engineer's signature																																					
Customer's signature (To confirm satisfactory demonstration and receipt of manufacturers' literature)																																					

SERVICE & INTERIM BOILER WORK RECORD

It is recommended that your boiler and heating system are regularly serviced and maintained, in line with manufacturers' instructions, and that the appropriate service / interim work record is completed.

Service provider

When completing a service record (as below), please ensure you have carried out the service as described in the manufacturers' instructions. Always use the manufacturers' specified spare parts.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Electrode changed? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Electrode changed? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Electrode changed? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Electrode changed? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Electrode changed? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Electrode changed? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE & INTERIM BOILER WORK RECORD

It is recommended that your boiler and heating system are regularly serviced and maintained, in line with manufacturers' instructions, and that the appropriate service / interim work record is completed.

Service provider

When completing a service record (as below), please ensure you have carried out the service as described in the manufacturers' instructions. Always use the manufacturers specified spare parts.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Were parts fitted? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Were parts fitted? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Were parts fitted? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Were parts fitted? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Were parts fitted? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

SERVICE/INTERIM WORK ON BOILER <small>delete as appropriate</small>				Date:	
Engineer name:		Company name:			
Telephone N°:		Gas Safe registration N°:			
Max rate	CO	ppm	CO ₂	%	CO/CO ₂
Min rate	CO	ppm	CO ₂	%	CO/CO ₂
Where possible, has a flue integrity check been undertaken in accordance with manufacturers' instructions, and readings are correct?*				yes	
Gas rate:	m³/h	OR	ft³/h		
Were parts fitted? <small>delete as appropriate</small>				Yes	No
Parts fitted:					
System inhibitor concentration has been checked and appropriate action taken, in accordance with BS 7593 and boiler manufacturers' instructions. *				yes	n/a
Comments:					
Signature:					

*A System inhibitor efficacy test is required on every annual service in accordance with the manufacturers' instructions and BS 7593. It is only acceptable to not have undertaken this if the service engineers attendance visit was in between annual services to attend a non-water facing component.

[illegible]



17962.3949.0

4124

88A5

UK



Biasi UK Ltd

Commercial Road

Leamore Enterprise Park

WALSALL

WS2 7NQ

Sales Tel. 01922 714600

Tech. Service Tel. 01922 714636

www.biasi.co.uk

