Wall hung, fanflue, roomsealed, high efficiency gas boiler

Service manual

RINNOVA ADAPTIVE

Product name	Models	G.C. Appl. No.
RINNOVA ADAPTIVE 25C	M300V.2025 SM	47-583-46
RINNOVA ADAPTIVE 30C	M300V.2530 SM	47-583-47
RINNOVA ADAPTIVE 35C	M300V.3035 SM	47-583-48

Leave this manual adjacent to the gas meter

Warning:

Service / repairs must be carried out, only by a qualified Gas Safe Registered Engineer, who will be responsible for the current Regulations for gas appliances.

Note:

After servicing, complete the relevant Service Interval Record section of the Benchmark Checklist of the user and installation manual.





TABLE OF CONTENTS

1	OVERALL INFORMATION	12 PR	IMARY CIRCUIT PRESSURE SWITCH35
	.1 Overall View	12.1	Function
	.2 Hydraulic diagram	12.2	Removal
2	GENERAL ACCESS AND EMPTYING HYDRAULIC		PANSION VESSEL AND PRESSURE GAUGE36
2	CIRCUITS	13.1 13.2	Function
	2.2 Case panels	13.2	Removal of the expansion vessel
	2.3 Control panel		·
2	2.4 Main electronic p.c.b. box		I.W. FLOW METER, FILTER AND FLOW LIMITER 37
2	2.5 Emptying the primary circuit	14.1 14.2	Function
2	2.6 Emptying the D.H.W. circuit	14.2	14.3)
3	DIAGRAMS8	14.3	Removal of the sensor
3	3.1 Wiring diagram M300V SM	14.4	Checks
3	3.2 Circuit voltages	14.5	Removal of the flow meter group and D.H.W. circuit filter 38
4	FAULT FINDING	15 NT	C HEATING DELIVERY PROBE - NTC MAXIMUM
	J.1 Display diagnostic		MPERATURE, C.H. TEMPERATURE RETURN PROBE
4	Error history (view only)	NT	C, D.H.W. TEMPERATURE PROBE NTC39
4	Programming the maintenance period	15.1	Function
5	CONDENSING HEAT EXCHANGER15	15.2	Checks
5	5.1 Function15	15.3	Removal of the NTC heating delivery probe - NTC
5	5.2 Removal	15.4	maximum temperature
5	5.3 Cleaning	15.5	Removal of the D.H.W. temperature probe NTC40
6	D.H.W. HEAT EXCHANGER	40 DV	·
6	5.1 Function17	16 B f	-PASS VALVE
6	3.2 Removal	16.2	Removal
7	PUMP		
7	7.1 Function		N AND AIR BOX
7	7.2 Removal pump head	17.1 17.2	Function
8	THREE WAY DIVERTER VALVE19		
	3.1 Function		NITION / DETECTION ELECTRODE AND BURNER43
8	3.2 Checks19	18.1 18.2	Function
8	Removal of the electric actuator	18.3	Removal of the front insulation panel
	Removal of the three way diverter valve	18.4	Removal of the burner
8	Removal of the diverter group	18.5	Removal of the rear insulation
9	MAIN ELECTRONIC CONTROL/IGNITION P.C.B	18.6	Checks44
S	9.1 Function21	19 FI I	UE TEMPERATURE PROBE NTC AND SAFETY
	9.2 Selection and adjustment devices		ERMAL FUSE
	22 O.4 Setting the boiler control function modes	19.1	Function
	0.5 Checks	19.2	Removal
	9.6 Removal of the electronic control p.c.b	19.3	Checks46
ç	7.7 Thermal control in the mode	20 CO	NDENSATE TRAP
6	0.8 Thermal control in the 🎹 mode	20.1	Function48
10	CONTROL PANEL ELECTRONIC P.C.B	20.2	Check the cleanness of the trap
	0.1 Function	20.3	Removal
1	0.2 Normally information	21 SH	ORT SPARE PARTS LIST49
11	GAS VALVE31		
	1.1 Function		
1	1.2 Description of the parts		
1	1.3 Adjustment - Chimney Sweep Function		
	1.4 Automatic calibration of the gas valve32		
	1.5 Checks		
1	1.6 Removal of the gas valve		

OVERALL INFORMATION

OVERALL INFORMATION

1.1 Overall View





Figure 1.1

1.2 Hydraulic diagram

Central heating (C.H.) operation C.H. C.H. water flow

water return



D.H.W. D.H.W. inlet outlet

Domestic hot water (D.H.W.) operation

Figure 1.2

GENERAL ACCESS AND EMPTYING HYDRAULIC CIRCUITS

2 GENERAL ACCESS AND EMPTYING HYDRAULIC CIRCUITS

2.1 Nomenclature




Figure 2.1

- 1 Right side panel
- 2 Front panel
- 3 Main electronic p.c.b. box
- 4 Control panel
- 5 Left side panel

2.2 Case panels



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

For the most part of the check and maintenance operations it is necessary to remove one or more panels of the case.

The side panels can be removed only after the removal of the front panel.

To remove the front panel loosen screws "6" (Figure 2.2), lift the panel and remove it.




Figure 2.2 - Bottom view of the boiler

Pull the lower part of the front panel and lift it upwards (Figure 2.3).




Figure 2.3

To remove the side panels loosen the screws "7" (Figure 2.2) and "8" (Figure 2.3).

Pull the side panels towards the outside.

To Fit the case panels

Fit the side case panels.



Warning: Fit the front panel hooking it on the upper side.

Fit the side panels and the front panel in the reverse order to that described above.


2.3 Control panel



Warning: isolate the boiler from the mains electricity supply before removing any covering or component

To gain access to the parts located inside the control panel proceed as follows:

- 1 Remove the front panel of the case
- 2 Unscrew the screw "9" and turn the control panel "10" (Figure 2.4)



GENERAL ACCESS AND EMPTYING HYDRAULIC CIRCUITS

2.4 Main electronic p.c.b. box



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

Terminal block lid removal

To gain access to the parts located inside the control panel proceed as follows:

- Remove the front panel of the case.
- Turn the control panel "11" (see section "2.3 Control panel" on page 5).
- Unscrew the screw "12" and lift the cover "13" to access the electric power supply terminal block, remote and external sensor (Figure 2.5).




Figure 2.5

Rotate the lid (Figure 2.6).




Figure 2.6

Main electronic p.c.b. lid removal

To get access to the main electronic p.c.b.:

5 Unscrew the screw "14" (Figure 2.7).





Figure 2.7

Free the hooks indicated and rotate the cover "16" and the lids "15" (Figure 2.8).



7 Free the hooks indicated and rotate the cover "17" (Figure 2.9).




Figure 2.9

GENERAL ACCESS AND EMPTYING HYDRAULIC CIRCUITS

2.5 Emptying the primary circuit

1 Close the C.H. circuit flow and return cocks "18" (Figure 2.10).




Figure 2.10

- 2 Remove the front and right panels of the boiler.
- 3 Loosen the central heating drain cock "20" (Figure 2.11) until the boiler is completely emptied.





Figure 2.11

4 To make draining easier, lift the plug "21" of the automatic relief valve in Figure 2.12.



2.6 Emptying the D.H.W. circuit

- 1 Close the D.H.W. inlet cock "19" (Figure 2.10).
- 2 Open one or more hot water taps until the boiler has been completely emptied.

DIAGRAMS

3 DIAGRAMS

3.1 Wiring diagram M300V SM





Figure 3.1

DIAGRAMS

3.2 Circuit voltages






Figure 3.2

4 FAULT FINDING

	1	External temp. probe								4											
	ı	Pressure gauge				4															
	ı	Safety valve																			
	- (2)	Expansion vessel																			
	20.1	Flue temp. probe NTC									В										
	9.2 2	Gas restrictor																			
	19.2 19.2	Safety thermostat		ш																	
	18.4	Ignition / Detection electrode	ပ									ш									
	17 1	Fan / air restrictor					4														
	16	By-pass valve																			
		D.H.W. temp. probe							4												
	15.2	Main circuit temp. probe						⋖					4								
	14.5	D.H.W. filter																			
heck	11.4 12.2 14.5	Main circuit pressure switch		4														4			
Components to check	11.4	Gas valve	۵																В	В	4
onent	10	Control panel electr. p.c.b.																			
omp		Boiler settings																			
	9.5	Main electronic p.c.b.			4							ပ							4	⋖	Ф
		Fuses (Electronic p.c.b.)																			
	14.3	D.H.W. flow meter																			
	8.2	Diverter valve																			
	7.2	dmnd				В								В	В	В	4				
	9	D.H.W. heat exchanger																			
	2	Condensing heat exchanger		ပ											ပ		В				
	(4)	D.H.W. circuit																			
	7)	C.H. circuit												٧	∢	۷					
	21.1	Cond. drain pipe and trap	В																		
	- (3)	Flue pipes									⋖										
	-(2)	Gas supply line	4																		
	- E	Power supply line																			
	Section of the manual → (note ref. in brackets)	Appliance lock−out (*) ← ©fe of ock−out (*)	E01 + RESET	E02 + RESET	E03 + RESET	E04 + 3-C	E05 + 3—€	E06 + 3-C	E07 + 3 C	E08 + 3€	E10 + 3 C	E11 + RESET	E12 + 🕶	E13 + 3 C	E14 + RESET	E14 + >=	E18 + RESET	E-19 + C+ C	E20 + RESET	हो E21 + RESET	E22 + RESET

The letter in the cells indicates the possible fault cause. **A....Z** indicates the most probably (**A**) to less probably (**...Z**)

FAULT FINDING

	,	External temp. probe																			
		Pressure gauge																			
																					-
	1	Safety valve																			
	- (-)	Expansion vessel																			
	2 20.1	Flue femp. probe NTC		ω																	
	18.4 19.2 19.2	Gas restrictor																			
	19.	Safety thermostat																			
		Ignition / Detection electrode			В				4					٧	4			8			
	17	Fan / air restrictor																			
	16	By-pass valve																			
	15.2	D.H.W. temp. probe																			
		Main circuit temp. probe				٧															
	14.5	D.H.W. filter																			
Components to check	11.4 12.2	Main circuit pressure switch																			
ts to o	4.11	Gas valve	В						ပ												
onen	10	Control panel electr. p.c.b.																			
Somp		Boiler settings																			
	9.5	Main electronic p.c.b.	4		۷	ပ		∢	ш	⋖	⋖	⋖	ш	В	В	ш	ш	4		۷	
		Fuses (Electronic p.c.b.)																			
	14.3	D.H.W. flow meter																			
	8.2	Diverter valve																			
	7.2	Pump				В															
	9	D.H.W. heat exchanger																			<
	2	Condensing heat exchanger																			
		D.H.W. circuit																			
	- (4)	C.H. circuit																			
	21.1	Cond. drain pipe and trap																			
	(3)	Flue pipes		4																	
	(2)	Gas supply line			ပ				٥				4			4					
	- ()	Power supply line					⋖										∢		∢		
	Section of the manual → (note ref. in brackets)				 -				 -								_	_			
	man		Y	4	ESE	Y	Y	Y	ESE	4	4	4	Y	Y	Y	Y	ESE	ESE	Y	ا ۲	
	of the	Defect ←	E23 + 3-C	E24 + 3—C	E25 + RESET	E26 + 3—C	E40 +)	E42 + 2	E44 + RESET	E50 + 3	E62 + 3	E65 + 3—C	E68 + 2	E77 + 3—C	E79 + 3—C	E78 + 3	E89 + RESET	E91 + RESET	E97 + 3—C	E99 + 3—C	
	ction te ref		E2;	E2,	E2	E2(E4	E4:	<u>Н</u>	E5(E6.	E6	E6	E7.	E7;	E7					7
	Se (no	Appliance lock-out (*)															Ε"	" səti	soibn	ii ysk	ısiQ

The letter in the cells indicates the possible fault cause. A....Z indicates the most probably (A) to less probably (...Z)

			FAUL	-			_					
1	External temp. probe										•	•
1	Pressure gauge										•	•
ı	Safety valve										•	•
- (2)	Expansion vessel										•	
	Flue temp. probe NTC							•				
9.2	Gas restrictor											
9.2	Safety thermostat											
8.4	electrode											
	Fan / air restrictor					•	•	•				
	By-pass valve						•		•			
	D.H.W. temp. probe					•						
15.	Main circuit temp. probe					•			• (8)	•		
14.5	D.H.W. filter											
12.2	Main circuit pressure switch											
	Gas valve						•					
10	Control panel electr. p.c.b.	•										
	Boiler settings											
9.5	Main electronic p.c.b.	•	•		•	•		•				
	Fuses (Electronic p.c.b.)	•										
14.3	D.H.W. flow meter		•		•							
8.2	Diverter valve		•		•				•			
7.2	dmnA						•					
9	D.H.W. heat exchanger								•	•	•	
2	Condensing heat exchanger											
. (D.H.W. circuit									•		
1 4)	C.H. circuit										•	
21.1	Cond. drain pipe and trap											
- (6)	Flue pipes						•	•				
- (2)	Gas supply line						•	•				
- (£)	Power supply line	•										
Section of the manual → (note ref. in brackets)	Defect →	The boiler does not start either in C.H. or D.H.W. mode. The control panel display OFF Fan still.	The boiler does not supply D.H.W. (cold water from the tap). Regular operation in C.H. mode even during a drawing off D.H.W.	On C.H. mode the temperature of the main circuit reaches 90°C and the C.H. evetem	does not heat. The boiler operates correctly on D.H.W. mode.	Incorrect modulation.	Noisy bolier.	Poor C.H. / D.H.W. temperature (9).	Poor D.H.W. temperature. Regular opera- tion in C.H. mode.	Low D.H.W. flow rate.	Water leaks from the safety valve during operation on C.H.	Water leaks from the safety valve when the
	- - - 21.1 - 5 6 7.2 8.2 14.3 9.5 10 11.4 12.2 14.5 15.2 16 17 18.4 19.2 19.2 20.1 - - - -	Power supply line 1	Power supply line Case supply Case supply Case supply Case supply line Case supply Case	1	1	1	1	1	1	1	1	1

* Lock out is indicated as "E" on the display.

Note Useful information can be obtained also from the optical indication given by the appliance display (see section 4.1).

Verify the integrity of supply cable, plug and external fuses. Check for 230V~ between line (L) and neutral (N). Check the polarity of line and neutral connection. _

- Check the gas supply pipe and isolation tap for gas tightness. Check for soundness and absence of obstructions. Verify that the flue terminal is correctly installed (see clearances) Check for soundness of the circuit and verify its correct filling and ensure that exhaust gas is not sucked back by the boiler. (see also installation manual). 0 0
- A jammed by-pass could cause the over-heating of the main circuit and the intervention of the safety thermostat. 2
- Using the flue analyser, check the CO₂ value of the flue gases. 9
 - This reading is a reference value for the gas valve setting. Check the pressurization of the expansion vessel. Refer to the installation manual for proper values.
- D.H.W. pressure too high or flow rate too high. If necessary insert a flow rate limiter (14.6). ω 0
 - The boiler doesn't reach the nominal heat input.


4.1 Display diagnostic

The display indications provide help in the diagnosis of fault finding

The control panel display gives other information for the user.

The following table gives fault code, error and the reason for the fault.

E04 - DE0EE	0.64.1.1.4.1.6.11.11.11
E01 + RESET	Safety lockout due to failed ignition.
E02 + RESET	Lockout due to safety thermostat.
E03 + RESET	Generic lockout.
E04 + >	Pump circulation failure, insufficient system
	pressure or water pressure sensor not connected.
E05 + > → C	Control anomaly: fan.
E06 + > → c	NTC heating delivery probe failure.
E07 + 3€	D.H.W. NTC probe failure / Hot water tank sensor failure.
E08 + 3← €	External NTC probe failure.
E10 + >—c	Lockout due to tripping of the flue gas probe and thermal fuse.
E11 + RESET	Parasite flame.
E12 + 3—c	Return NTC probe failure.
E13 + 3—c	Delta T M-R > 40K.
E14 + 3—C	Temperature gradient circulation failure (>2K/s).
E14 + RESET	Pump fault or primary temperature above 105°C.
E18 + RESET	No ΔT heating at startup.
E19 + 3← €	Auxiliary Input Probe Anomaly.
E20 + RESET	EVG lockout (valve piloting hardware failure).
E21 + RESET	EVG lockout (valve control Relay Failure).
E22 + RESET	EVG lockout (flame after closing valve Ref. EVG).
E23 + 3─ €	Gas valve modulator disconnected.
F04 : 5	Anomaly due to probable chimney obstruc-
E24 + 3—C	tion.
E25 + RESET	tion. Flame loss for more than 6 consecutive times.
	Flame loss for more than 6 consecutive
E25 + RESET	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heat-
E25 + RESET	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes.
E25 + RESET E26 + 3—C E40 + 3—C	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency.
E25 + RESET E26 + 3—C E40 + 3—C E42 + 3—C	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without
E25 + RESET E26 + 3-C E40 + 3-C E42 + 3-C E44 + RESET	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without flame.
E25 + RESET E26 + 3-C E40 + 3-C E42 + 3-C E44 + RESET E50 + 3-C	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without flame. OT communication fault.
E25 + RESET E26 + 3-C E40 + 3-C E42 + 3-C E44 + RESET E50 + 3-C E62 + 3-C	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without flame. OT communication fault. Calibration request. System fails to control combustion and exits
E25 + RESET E26 + 3-C E40 + 3-C E42 + 3-C E44 + RESET E50 + 3-C E62 + 3-C E65 + 3-C	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without flame. OT communication fault. Calibration request. System fails to control combustion and exits modulator control parameters.
E25 + RESET E26 + 3 C E40 + 3 C E42 + 3 C E44 + RESET E50 + 3 C E62 + 3 C E65 + 3 C E68 + 3 C	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without flame. OT communication fault. Calibration request. System fails to control combustion and exits modulator control parameters. Probably low gas pressure.
E25 + RESET E26 + 3-C E40 + 3-C E42 + 3-C E44 + RESET E50 + 3-C E62 + 3-C E68 + 3-C E77 + 3-C	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without flame. OT communication fault. Calibration request. System fails to control combustion and exits modulator control parameters. Probably low gas pressure. System out modulator control parameters.
E25 + RESET E26 + 3-C E40 + 3-C E42 + 3-C E44 + RESET E50 + 3-C E65 + 3-C E68 + 3-C E77 + 3-C E79 + 3-C	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without flame. OT communication fault. Calibration request. System fails to control combustion and exits modulator control parameters. Probably low gas pressure. System out modulator control parameters. System out modulator control parameters. Possible low gas pressure. Internal error (usually hardware) or problems with the mains electrical supply (excessive distortion of waveform).
E25 + RESET E26 + 3 C E40 + 3 C E42 + 3 C E44 + RESET E50 + 3 C E62 + 3 C E68 + 3 C E77 + 3 C E79 + 3 C E78 + 3 C	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without flame. OT communication fault. Calibration request. System fails to control combustion and exits modulator control parameters. Probably low gas pressure. System out modulator control parameters. System out modulator control parameters. Possible low gas pressure. Internal error (usually hardware) or problems with the mains electrical supply (excessive
E25 + RESET E26 + 3 C E40 + 3 C E42 + 3 C E44 + RESET E50 + 3 C E65 + 3 C E68 + 3 C E77 + 3 C E79 + 3 C E89 + RESET	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without flame. OT communication fault. Calibration request. System fails to control combustion and exits modulator control parameters. Probably low gas pressure. System out modulator control parameters. System out modulator control parameters. Possible low gas pressure. Internal error (usually hardware) or problems with the mains electrical supply (excessive distortion of waveform).
E25 + RESET E26 + 3 C E40 + 3 C E42 + 3 C E44 + RESET E50 + 3 C E62 + 3 C E65 + 3 C E77 + 3 C E79 + 3 C E89 + RESET	Flame loss for more than 6 consecutive times. Maximum deviation fault between the 2 heating NTC probes. Detection of incorrect mains frequency. Buttons fault. Fault of cumulative gas valve timeout without flame. OT communication fault. Calibration request. System fails to control combustion and exits modulator control parameters. Probably low gas pressure. System out modulator control parameters. System out modulator control parameters. Possible low gas pressure. Internal error (usually hardware) or problems with the mains electrical supply (excessive distortion of waveform). Maximum number of lockouts reached.



4.2 Error history (view only)

1 To enter in the parameters setting mode press at the same time the 2 keys "B" and "D" (Figure 4.1) and hold in for 5 second until the LCD display indicates the letters **HiS** Figure 4.2.




Figure 4.1



Figure 4.2

- 2 To enter the selected menu press key "C" (Figure 4.1) for 1 second.
- 3 Scroll the various fault code using keys "B" or "D" (Figure 4.1).
- 4 To exit the parameters menu.
- · wait 15 minutes without pressing any key;
- switch off the electric power supply;
- press the "B" and "D" keys simultaneously for 5 seconds (Figure 4.1) (return to previous level).

4.3 Programming the maintenance period

1 To enter in the parameters setting mode press at the same time the 2 keys "B" and "D" (Figure 4.3) and hold in for 5 second until the display shows Figure 4.4.




Figure 4.3



Figure 4.4

- 2 Scroll the various menus using keys "B" or "D" (Figure 4.3) until the LCD display indicates the letters PAr (Figure 4.5).
- 3 To enter the selected menu press key "C" (Figure 4.3) for 1 second.



Figure 4.5

4 Scroll the various menus using keys "B" or "D" (Figure 4.3) until the LCD display indicates the letters **P34** until the LCD display indicates the value of parameter 34 (e.g.**12** default value) Figure 4.6.



Figure 4.6

5 To enter the selected parameter press key "C" (Figure 4.3) for 1 second. The display will show the following (Figure 4.7).



Figure 4.7

- 6 Pressing keys "B" or "D" makes it possible to change the value of parameter 34 from **0** to **48** months. It is possible to set parameter 34 to **99** thereby disabling the maintenance request (symbol **>** will disappear from the display).
- 7 By pressing key "C" (Figure 4.3) confirmation of the inserted value is obtained. The display will show the following (Figure 4.8) for 5 seconds, then move up to the next level.



Figure 4.8

- 8 To exit the parameters menu.
- · wait 15 minutes without pressing any key;
- switch off the electric power supply;
- press the "B" and "D" keys simultaneously for 5 seconds (Figure 4.3) (return to previous level).

CONDENSING HEAT EXCHANGER

5 CONDENSING HEAT EXCHANGER

5.1 Function

The Condensing heat exchanger "1" in Figure 5.1 has the function of transferring heat produced from combustion of the gas and from the flue exhausted gas to the water circulating in it.




Figure 5.1

By reducing the combustion products temperature, the latent heat of the vapour is transferred to the water circuit, allowing an extra gain of useful heat.

The condensed vapour is then drained through the condensate trap "3" and the draining pipe "2".

5.2 Removal



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Disconnect the flue system from the boiler.
- 2 Remove the fan group (rubber pipe, gas pipe) following the instructions from 1 to 6 in section "17.2 Removal of the Air box and the Fan" on page 42.
- 3 Disconnect the detection / ignition electrode connector "4".
- 4 Disconnect the fan connector "5" by pressing the plastic hook placed on the side of the connector (Figure 5.2).
- 5 Unscrew the nuts "6" (Figure 5.2).
- 6 Remove the fan-burner group "7".
- 7 Empty the primary circuit of the boiler.
- 8 Remove the clips "8" (Figure 5.2).
- 9 Loosen the connection "10" and slightly move the pipe "9" upwards, turn it towards left (Figure 5.2) and then move the pipe downwards freeing it from the Condensing heat exchanger.
- 10 Loosen the connection "11" and slightly move the pipe "12" upwards, turn it towards left (Figure 5.2) and then move the pipe downwards freeing it from the Condensing heat exchanger.





Figure 5.2



- 11 Unscrew the screws "13" and remove the clamps (Figure 5.3).
- 12 Disconnect the connector "14" by pressing the plastic hook placed on the side of the connector (Figure 5.3).
- 13 Remove the Condensing heat exchanger by levering it and sliding it forwards.
- 14 Reassemble the Condensing heat exchanger carrying out the removal operations in reverse order.

CONDENSING HEAT EXCHANGER

Ensure to tighten the nuts "6" - Figure 5.2 firmly.

5.3 Cleaning

If there are deposits of dirt on the coil of the Condensing heat exchanger, clean with a bristle paintbrush and remove the dust with a hoover.



Warning: After cleaning or replacement as detailed above, it is deemed necessary to undertake a combustion analysis as detailed in chapter "11.3 Adjustment - Chimney Sweep Function" on page 31.




Figure 5.4

Caution:

After any periodical servicing or disturbance the combustion chamber silicon seal "15" Figure 5.4 must be fully inspected and replaced at the discretion of the service engineer.

After any disturbance to the chamber door seal the appliance must undergo a full analytical combustion performance check.



Remove any limescale from the detection electrode and replace it if worn.

D.H.W. HEAT EXCHANGER

6 D.H.W. HEAT EXCHANGER

6.1 Function

The D.H.W. heat exchanger "1" in Figure 6.1 and Figure 6.3 allows the instantaneous transfer of heat from the primary hydraulic circuit to the water destined for D.H.W. use.




Figure 6.1

The schematic structure is shown in Figure 6.2.





Figure 6.2

6.2 Removal



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove the panels of the case.
- 2 Empty the primary circuit and the D.H.W. circuit of the boiler.
- 3 Remove the control panel following the instructions from 4 in section 2.3.
- 4 Remove main electronic p.c.b. box following the instructions from 5 in section 2.4.
- 5 Completely unscrew the Allen key screws "2" in Figure 6.3 which hold the exchanger to the groups.



6 Move the exchanger towards the rear of the boiler and extract it to the left.

Reassemble the D.H.W. heat exchanger carrying out the removal operations in the reverse order.



Warning: to lubricate the O-ring gaskets exclusively use a silicone base grease compatible to be in contact with foods and approved by the local water Authorities.



Warning: When reassembling the exchanger be sure to put the off center location/securing pin indicated in Figure 6.4 towards the left side of the boiler.




Figure 6.4

PUMP

7 PUMP

7.1 Function

The pump "1" in Figure 7.1 and Figure 7.2 has the function of making the water in the main circuit circulate through the main condensing heat exchanger and therefore through the C.H. system (during the C.H. function) or through the secondary heat exchanger (during the D.H.W. function).




Figure 7.1



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

Check that the pump is not seized and that the movement of the rotor is not subject to mechanical impediments.

With the boiler off, remove the front panel. Remove the air release plug of the pump and turn the rotor with a screwdriver.

Check that the impeller is correctly connected to the rotor shaft and that the rotor moves freely.

With the boiler off remove the front and right hand side case panels, lower the control panel and empty the primary circuit. Remove the pump head by undoing the screws which hold it to the pump body and check that the impeller is firmly joined to the rotor.

7.2 Removal pump head



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove the front case panel.
- 2 Empty the primary circuit of the boiler.
- 3 Disconnect the connector "2" (Figure 7.2).
- 4 Unscrew the four screws "3" and remove the pump head "1".




Figure 7.2

Reassemble the pump head carrying out the removal operations in the reverse order. When reassembling the pump head, check the correct position of the gasket and tighten the screws "3" proceeding diagonally around the pump.

THREE WAY DIVERTER VALVE

8 THREE WAY DIVERTER VALVE

8.1 Function

The diverter valve "1" (Figure 8.1) has the function of modifying the hydraulic circuit of the boiler by means of an electric command given by the electronic control p.c.b. in order to send the water that exits the primary heat exchanger towards the C.H. system or towards the D.H.W. heat exchanger.




Figure 8.1

8.2 Checks



Warning: check the electrical continuity.

Figure 8.2 indicates the relationship between the electric command coming from the electronic control p.c.b. and the position of the actuator "2" (brass spindle) when the boiler operates in **D.H.W. mode**.

Figure 8.3 indicates the relationship between the electric command coming from the electronic control p.c.b. and the position of the actuator "2" (brass spindle) when the boiler operates in **C.H. mode**.

In both figures the relationship between the position of the actuator and the resistance of the motor windings (the motor must be disconnected from the wiring before undertaking any resistance tests) is also given.




Figure 8.2 D.H.W. mode




Figure 8.3 C.H. mode

8.3 Removal of the electric actuator



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove the front case panel.
- 2 Disconnect the connectors "3" (Figure 8.4).
- 3 Remove the fixing spring "4" and remove the actuator 5.

 Reassemble the actuator carrying out the removal operations in the reverse order.

When reassembling the actuator, refer to Figure 8.3 or to the wiring diagram in section "3 Diagrams" on page 8 for the correct wiring connection.

THREE WAY DIVERTER VALVE



Warning: Please note the electric actuator is energized 240VAC even if the boiler is in a standby condition.




Figure 8.4

8.4 Removal of the three way diverter valve

- 1 Remove the front and both side case panels.
- 2 Empty the primary circuit and the D.H.W. circuit of the boiler.
- 3 Remove the electric actuator (see "8.3 Removal of the electric actuator" on page 19).
- 4 Unscrew the three way diverter valve "6" Figure 8.5.




Figure 8.5

Reassemble the three way diverter valve carrying out the removal operations in the reverse order.



Warning: to lubricate the O-ring gaskets exclusively use a silicone base grease compatible to be in contact with foods and approved by the local water Authorities.

8.5 Removal of the diverter group

- 1 Remove the front and both side case panels.
- 2 Empty the primary circuit and the D.H.W. circuit of the boiler.
- 3 Remove the electric actuator (section "8.3 Removal of the electric actuator" on page 19).
- 4 Disconnect D.H.W. temperature probe NTC "7" (Figure 8.6).

- 5 Unscrew the connector "8" (Figure 8.6), the C.H. flow connector and the D.H.W. outlet connector.
- 6 Remove the D.H.W. heat exchanger (see "6.2 Removal" on page 17).
- 7 Unscrew the screw "9" and remove the diverter group.




Figure 8.6

8 Reassemble the diverter group carrying out the removal operations in the reverse order.



Warning: to lubricate the O-ring gaskets exclusively use a silicone base grease compatible to be in contact with foods and approved by the local water Authorities.

9 MAIN ELECTRONIC CONTROL/IGNITION P.C.B.

9.1 Function

Inlet Information

On the *Main electronic control/ignition* p.c.b......

Function control

C.H. temperature adjustment

D.H.W. temperature adjustment

Boiler reset button

(printed circuit board p.c.b.)

From other boiler devices....

C.H. temperature probe NTC

D.H.W. temperature probe NTC

D.H.W. flow meter

Primary circuit pressure switch


Flue temperature probe NTC

Safety thermostat

Flame detection electrode

Room thermostat (if fitted)

Time switch (if fitted)



Outlet command

Pump

Three way diverter valve

Gas valve

Fan

Ignition electrodes

Display indicates "E"*

*control panel electronic p.c.b.

Figure 9.1

The fundamental function of the *Main electronic control/ignition p.c.b.* is that of controlling the boiler in relation to the external needs (i.e. heating the dwelling or heating the water for D.H.W. use) and operating in order to keep the temperature of the hydraulic circuits constant.

This is obviously possible within the useful power and maximum working temperature limits foreseen.

Generally, the *Main electronic control/ignition p.c.b.* receives inlet information coming from the boiler (the sensors) or from the outside (printed circuit board p.c.b., room thermostat, etc.), processes it and consequently acts with outlet commands on other components of the boiler (Figure 9.1).

The *Main electronic control/ignition p.c.b.* is also a full sequence ignition device and does a sequence of operations (ignition cycle) which lead to the ignition of the gas at the burner.

It checks the presence of the flame during the entire period in which it is activated and supplies the fan regulating its speed.

The *Main electronic control/ignition p.c.b.* has a safety function and any incorrect interventions or tampering can result in conditions of dangerous functioning of the boiler.

The Main electronic control/ignition p.c.b. can lock the functioning of the boiler (lock state) and stop its functioning up to the resetting intervention. The lock-out is signalled on the display of the printed circuit board p.c.b. and can be reset only by using the boiler reset button placed on the control panel electronic p.c.b. (see section "10.1 Function" on page 28).

Some components which are connected to the device can activate the lock state. The causes of a lock state could be:

- The intervention of the safety thermostat (overheat of the primary circuit).
- The intervention of the flue temperature probe (overheat of the combustion products).
- A fault on gas supply.
- Faulty ignition (faulty ignition electrodes, their wiring or connection).
- Faulty flame detection (faulty detection electrode, its wiring or connection).
- · Faulty condensate drainage.
- Faulty gas valve (faulty on-off operators or not electrically supplied).
- Faulty Main electronic control/ignition p.c.b..

Other components like the primary circuit pressure switch can temporarily stop the ignition of the burner but allow its ignition when the cause of the intervention has stopped.

Figure 9.12 and Figure 9.13 show the sequence of the operations that are carried out at the start of every ignition cycle and during normal functioning.

9.2 Selection and adjustment devices

On the *Main electronic control/ignition p.c.b.* several selection, adjustment and protection devices are located. (Figure 9.2).

Some of these devices are directly accessible by the user (function control, temperature adjustment etc.) others, like the fuses, are accessible by removing the main electronic p.c.b. lid.




Figure 9.2

- Connector electric supply p.c.b. 1
- 2 Fuse F1 3,15 AF
- Connector 3 way diverter valve
- Connector pump
- Connector controller fan, flue temperature probe NTC, safety thermostat and C.H. temperature probe NTC
- Connector D.H.W. temperature probe NTC, D.H.W. flow meter and primary circuit pressure switch
- Connector gas valve
- Connector external temperature probe and remote control (optional)
- Connector ignition / detection electrode
- 10 Connector ground reference for ignition / detection electrode
- 11 Connector fan



The Main electronic control/ignition p.c.b. makes it possible to separately adjust the C.H. water flow temperature and D.H.W. outlet temperature.

The temperature of the water is converted into an electric signal by means of temperature probes.

The user, setting the desired temperature with the control panel p.c.b. key $\triangle \nearrow \nabla$ or $\triangle \square \nabla$.

If the power requested is lower than 40% of the maximum power output then control is achieved by switching ON the burner at minimum power, then switching OFF (ON/OFF function). If the power requested is higher, then the burner is switched ON at maximum power and will control by modulating to 40% of the maximum power output.

During the C.H. operation (Figure 9.3), the signal coming from the C.H. temperature probe is compared to the signal given by the control panel through the adjustment made by the user (key $\triangle \square \nabla$). The result of such a comparison operates the fan speed thus regulating the gas flow rate and consequently changing the useful output of the boiler.




Figure 9.3

When the boiler functions in D.H.W. (Figure 9.4), the signal coming from the D.H.W. temperature probe is compared with the signal given by the control panel through the adjustment made by the user (key $\triangle \not \models \nabla$).





Figure 9.4

Normally, the result of the comparison between these two signals directly operates the fan speed adjusting the useful output generated in order to stabilize the temperature of the exiting water. If during the D.H.W. mode operation, the temperature of the primary circuit goes over 90°C, the useful output is automatically reduced so that the primary circuit cannot reach excessive temperatures.

The control sequences in function $\parallel \parallel$ and $\parallel \parallel$ in function are illustrated in detail in sections "9.7 Thermal control in the mode" on page 26 and "9.8 Thermal control in the $\parallel \parallel$ mode" on page 27.



It is possible to select the various boiler control function modes hereafter named "parameters" by using the keys of the control panel p.c.b.

To enter in the parameters setting mode press at the same time the 2 keys "B" and "D" (Figure 9.5) and hold in for 5 second until the display shows Figure 9.6.




Figure 9.5



Figure 9.6

- 2 Scroll the various menus using keys "B" or "D" (Figure 9.5) until the LCD display indicates the letters PAr (Figure 9.7).
- 3 To enter the selected menu press key "C" (Figure 9.5) for 1 second.



Figure 9.7

4 To enter the selected parameter press key "C" (Figure 9.5) for 1 second. The display will show the following (Figure 9.8).





Figure 9.8

5 To enter the selected parameter press key "C" (Figure 9.5) for 1 second. The display will show the following (Figure 9.9).



Figure 9.9

- 6 Pressing keys "B" or "D" makes it possible to change the value of parameter.
- 7 By pressing key "C" (Figure 9.5) confirmation of the inserted value is obtained. The display will show the following (Figure 9.10) for 5 seconds, then move up to the next level.
- 8 By pressing the keys "B" and "D" simultaneously (Figure 9.5) exits the level without changing the value (return to the previous level Figure 9.10).



Figure 9.10

- 9 Scroll through the various parameters by pressing the keys "B" (back) or "D" (forward), until P02, which alternates with the parameter value, appears on the LCD display.
- 10 Repeat the previous steps to display the value and proceed to the next parameter.
- 11 To exit the parameters menu.
- · wait 15 minutes without pressing any key;
- switch off the electric power supply;
- press the "B" and "D" keys simultaneously for 5 seconds (Figure 9.5) (return to previous level).

Important: at the end of the setting operation it is important to fill/update the table in the installation manual see chapter COMMISSIONING section: Setting record.

PARAMETER	DIGIT	VALUES
Boiler model/type (M300V.2025 SM)		13
Boiler model/type (M300V.2530 SM)	P01	14
Boiler model/type (M300V.3035 SM)		15
	DO2	G20 = 00
Type of gas	P02	G31 = 01
User interface	P03	00
Type of domestic hot water exchanger	P04	00
Type of primary circuit control device	P05	03
Type of D.H.W. flow control device	P06	03
Maximum Temperature heating delivery (°C)	P07	80 °C
Minimum heating delivery temperature (°C)	P08	25 °C
Maximum heating output (%) (M300V.2025 SM)		79%
Maximum heating output (%) (M300V.2530 SM)	P09	75%
Maximum heating output (%) (M300V.3035 SM)		90%
Re-ignition frequency in heating mode (*10 sec.)	P10	6x60s
Adjusting the minimum pump speed (%)	P11	70%
Pump post-circulation (*10 sec.)	P12	6x60s
Pump mode operation	P13	0
Value of the external sensor K (K*10)	P14	0
Correct heating system pressure (*10 bar)	P15	3
Maximum heating system pressure limit	P16	30
ΔT heating delivery/return due to reduction of pump speed	P17	20
Adjusting maximum domestic hot water temperature	P18	55°C
Adjusting minimum temperature of domestic hot water	P19	35°C
Minimum closing flow rate of the D.H.W. flow meter (ON)	P20	20 l/min*10
Minimum opening flow rate of the D.H.W. flow meter (OFF)	P21	15 l/min*10
Ignition delay in D.H.W. mode	P22	5
Burner shut-off as a function of D.H.W. temperature	P23	0 -> 65°C
Burner ignition as a function of D.H.W. temperature	P24	2°C
D.H.W. pre-heating mode (M300V.2025 SM - M300V.2530 SM)	DOE	01
D.H.W. pre-heating mode (M300V.3035 SM)	P25	02
D.H.W. post-heating mode (at end of D.H.W.)	P26	00
Adjusting output power in D.H.W. mode (%) (M300V.2025 SM)		100%
Adjusting output power in D.H.W. mode (%) (M300V.2530 SM)	P27	90%
Adjusting output power in D.H.W. mode (%) (M300V.3035 SM)		100%
Adjusting maximum D.H.W. temperature in anti-legionella function (°C) (only for boilers with a sensor)	P28	0°C

PARAMETER	DIGIT	VALUES
Anti-legionella function activation frequency (days)	P29	3
Reset (restores factory settings)	P30	0
Chimney sweep	P31	0
Adjusting the minimum power in D.H.W. mode (%)	P32	0%
Regulation of the minimum power in heating mode (%)	P33	0%
Maintenance intervals (months)	P34	12
Antifreeze activation temperature	P35	5 °C
Antifreeze deactivation temperature	P36	35 °C
Antifreeze activation temperature with external sensor	P37	11 °C
External relay operating mode 1 (0=OFF, 1=Zone by remote, 3=Alarm)	P38	0
External relay operating mode 2 (0=OFF /TA2=OFF, 1=Zone heat. 2 / TA2 active, 2= EVG ext / TA2 Active, 3= Anomaly / TA2 Active, 4 =Remote filling / TA2 active)	P39	0
Size shown on the display during operation (0=T.CH or T.DHW, 1=only T.CH, 2=only T.DHW, 3=CH pressure, 4=T.ext, 10=CH Pressure in standby mode)	P40	10
Messages display (0=all, 1=boiler status and errors, 2=boiler status only)	P41	0
Not used	P42	
Not used	P43	
Not used	P44	
Not used	P45	
Not used	P46	
Not used	P47	
Maximum pump speed in heating mode (%)	P48	100
Maximum pump speed in D.H.W. mode (%)	P49	100
Not used	P50	
Not used	P51	
Chimney diaphragm (The nominal fan rpm reference value accordint to boiler model (P01) are increased or decreased according to the value set: 1=-200 rpm, 2=-150 rpm, 3=-100 rpm, 4=-50 rpm, 5=0 rpm, 6=+50 rpm, 7=+100 rpm, 8=+150 rpm, 9=+200rpm.)	P52	5
Fan speed at maximum	P53	232
Fan speed at minimum	P54	40
Ignition power (M300V.2025 SM)		156
Ignition power (M300V.2530 SM)	P55	132
Ignition power (M300V.3035 SM)		132
Gas valve management (0=standard mode, 1=reduced noise at minimum power rate)	P56	0
Type of external sensor (0=external probe not active, 1=external probe type NTC 12K, B = 3760, 2=external probe type NTC 10K, B = 3435)	P57	0

Tab 9.1

9.5 Checks

Check that the fuses are complete

If the Main electronic control/ignition p.c.b. does not supply any device (pump, fan, etc.) check that the fuses 2 (Figure 9.2) are complete.

If a fuse has blown replace it with one that has the same characteristics after having identified the reason for failure.

✓ Lock sequence

Start the boiler until the burner is ignited.

With the burner firing, interrupt the gas supply. The Main electronic control/ignition p.c.b. must carry out four complete ignition cycles and then, after about 4 minutes, goes to lock-out state. Switch off and on the electricity supply to the boiler, by means of the fused spur isolation switch, the device must not unlock and the burner must not turn on.


9.6 Removal of the electronic control p.c.b



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

When replacing the Main electronic control/ignition p.c.b. all parameters must be correctly checked / adjusted accordingly with the values noted in table in the installation manual see chapter COMMISSIONING section: Setting record (for information on parameters see also section "9.4 Setting the boiler control function modes" on page 23).

- 1 Remove all the body panels (see section "2.2 Case panels" on page 5).
- 2 Gain access to the parts located inside the Main electronic p.c.b. box as explained in the section "2.4 Main electronic p.c.b. box" on page 6 of this manual.
- 3 Unscrew the screws "1" (Figure 9.11).
- 4 Delicately flex the hooks "2" in the directions indicated (Figure 9.11) in order to release the circuit from the box.
- 5 Remove all the wiring connected to the Main electronic control/ignition p.c.b.
- 6 Remove the Main electronic control/ignition p.c.b.



7 Re-assemble the Main electronic control/ignition p.c.b. following the removal procedures in the reverse order.

Important

When re-assembling the Main electronic control/ignition p.c.b.:

8 It is not necessary to utilise static protections but it is advisable to ensure that the p.c.b. is handled with care and held at the edges and with clean dry hands.

Attention

After installing the *Main electronic control/ignition p.c.b.* properly set the parameters.



Warning: After cleaning or replacement as detailed above, it is deemed necessary to undertake a combustion analysis as detailed in section "11.3 Adjustment - Chimney Sweep Function" on page 31.

9.7 Thermal control in the mode




Figure 9.12

9.8 Thermal control in the ||| mode




Figure 9.13

CONTROL PANEL ELECTRONIC P.C.B.

10 CONTROL PANEL ELECTRONIC P.C.B.

10.1 Function




Figure 10.1

- A D.H.W. temperature increase key
- **B** D.H.W. temperature reduce key
- **C** Reset/Stand-by/Winter/Summer key
- **D** C.H. temperature reduce key
- E C.H. temperature increase key
- F Display

The Control panel electronic p.c.b. can give to the service 3 levels of informations:

- Normally information
- · Info modality
- · Function modes setting modality

10.2 Normally information KEY

训	All symbols with lines radiating from them indicate that the symbol is flashing.
	Stays on: D.H.W. function enabled. Flashing: D.H.W. function in progress.
*	Constantly illuminated: solar control unit connected. Flashing: solar pump operating.
111	Stays on: heating function enabled (winter). Flashing: heating function in progress.
٥	Constantly illuminated: 3 star preheating function active. Flashing: 3 star preheating function in progress.
O	Stays on: for 15s only after system loading. Flashing: in the case of low system pressure or if viewing the pressure from the INFO menu.
&	Stays on: flame present Flashing: drain upon ignition in progress.
-	Stays on: maintenance due pre-warning. Flashing: maintenance required or maintenance due.
RESET	Stays on: lockout error. The boiler can be restarted by the user, by pressing the reset button.
	Stays on: remote control connected. Flashing: request from remote control in progress.

SIGNAL DISPLAYED BY THE LCD

LCD	ED BY THE LCD FUNCTION
E01 + RESET	Safety lockout due to failed ignition.
E02 + RESET	Lockout due to safety thermostat.
E03 + RESET	Generic lockout.
E04 + 3—C	Pump circulation failure, insufficient system pressure or water pressure sensor not connected.
E05 + 3—c	Control anomaly: fan.
E06 + 3—c	NTC heating delivery probe failure.
E07 + 3—C	D.H.W. NTC probe failure / Hot water tank sensor failure.
E08 + 3—C	External NTC probe failure.
E10 + 3—c	Lockout due to tripping of the flue gas probe and thermal fuse.
E11 + RESET	Parasite flame.
E12 + 3—¢	Return NTC probe failure.
E13 + 3—C	Delta T M-R > 40K.
E14 + RESET	Pump fault or primary temperature above 105°C.
E14 + 3—¢	Temperature gradient circulation failure (>2K/s).
E18 + RESET	No ∆T heating at start-up.
E19 + 3—¢	Auxiliary Input Probe Anomaly.
E20 + RESET	EVG lockout (valve piloting hardware failure).
E21 + RESET	EVG lockout (valve control Relay Failure).
E22 + RESET	EVG lockout (flame after closing valve Ref. EVG).
E23 + 3—C	Gas valve modulator disconnected.

CONTROL PANEL ELECTRONIC P.C.B.

LCD	FUNCTION
E24 + 3—C	Anomaly due to probable chimney obstruction
E25 + RESET	Flame loss for more than 6 consecutive times.
E26 + 3—c	Maximum deviation fault between the 2 heating NTC probes.
E40 + 3—€	Incorrect mains frequency detected
E42 + 3─€	Buttons fault.
E44 + RESET	Fault of cumulative gas valve timeout without flame.
E50 + 3─€	OT communication fault.
E62 + 3—C	Calibration request.
E65 + 3—¢	System fails to control combustion and exits modulator control parameters
E68 + 3—c	Probably low gas pressure
E77 + >—c	System out modulator control parameters
E78 + 3─€	Possible low gas pressure
E79 + 3─ €	System out modulator control parameters
E89 + RESET	Internal error (usually hardware) or prob- lems with the mains electrical supply (excessive distortion of waveform).
E91 + RESET	Maximum number of lockouts reached.
E96	Incorrect network frequency.
E97	Power supply voltage low.
E99	Card not configured.
L1	Primary limitation in D.H.W. mode.
	Boiler stand-by, the dashes light up in sequence to simulate a scrolling motion (antifreeze protection activated).
### ### ### ##########################	When powering ON the boiler, all icons and digits light up (for 2 seconds) to check operation of the LCD.

LCD	FUNCTION		
E04%	If the pressure is not correct the value is displayed with the flashing symbol.		
	Next maintenance due date (factory setting 12 months). In the event of an error, this has greater priority than maintenance due date.		
	Maintenance overdue. In the event of an error, this has greater priority than maintenance due date.		
	Pump active for the post-circulation phase (flashing PO + flashing temperature).		
53			
5 5 P 111	Boiler in antifreeze phase (flashing bP +		
£ 15	flashing temperature).		
\$ 53	Boiler with D.H.W. power request. The D.H.W. temperature is displayed.		
	Boiler with central heating request via room thermostat.		
	Boiler with central heating power request with connected remote.		
78	Heating set temperature (all other symbols are disabled).		
* 45	D.H.W. set temperature (all other symbols are disabled).		

CONTROL PANEL ELECTRONIC P.C.B.

LCD	FUNCTION
- LJ - 53	Delay burner ignition due to system setting (flashing uu + flashing temperature).
- LP = 111	Boiler in chimney sweep function. To activate the chimney sweep function, set "parameter P32=1 4". The following is displayed: LP = minimum D.H.W. hP = minimum output in heating mode cP = maximum output in heating mode dP = maximum D.H.W. The transition occurs with buttons "E" (increase) and "B" (decrease) D.H.W.
53	3 star preheating function active. When the symbol (a) flashes, the function is in process.
53	Constantly illuminated: solar control unit connected. When the symbol * flashes, the solar circuit pump is in operation.

11 GAS VALVE

11.1 Function

The gas valve "1" in Figure 11.1 controls the gas inflow to the boiler burner.




Figure 11.1

By means of an electric command given to the on-off operators the passage of the gas through the Gas valve can be opened or closed.

11.2 Description of the parts (Figure 11.2)

- 2 Gas valve outlet pressure test point
- 3 On-off operators electric connector
- 4 Gas valve inlet pressure test point




Figure 11.2

11.3 Adjustment - Chimney Sweep Function



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.



Each time after measuring the gas pressure, fully close all tapping points that were used.

After each gas adjustment, the valve adjustment components must be sealed.



Warning: risk of electrocution.

The boiler is live during the operations described in this section.

Never touch any electrical parts.

Check the supply pressure before making any adjustment to the gas valve.

- 1 Close the gas inlet valve.
- 2 Remove the front panel of the case and lower the control panel (see sections "2.2 Case panels" on page 5 and "2.3 Control panel" on page 5).
- 3 Loosen the internal screw on the Inlet Pressure Test Point "4" (Figure 11.2) of the Gas valve and connect a pressure gauge using a suitable hose.
- 4 Open the gas inlet valve.
- 5 Read the inlet pressure value and ensure that it is within the limits given in the table Gas supply pressures, of the user/ installation manual. If it does not comply with the required pressure check the gas supply line and governor for faults and/or correct adjustment.
- 6 Switch off the boiler close the gas inlet valve.
- 7 Disconnect the pressure gauge and close the Inlet Pressure Test Point "4" (Figure 11.2).

Gas valve adjustment



The person carrying out a combustion measurement should have been assessed as competent in the use of a flue gas analyser and the interpretation of the results. The flue gas analyser used should be one meeting the requirements of BS7927 or BS-EN50379-3 and be calibrated in accordance with the analyser manufacturers' requirements, and have a current calibration certificate.

8 Fit the probe of the flue analyser in the flue exhaust sampling point located on the exhaust pipes of the boiler (Figure 11.3).




Figure 11.3

- 9 Turn on the boiler, switching on the fused spur isolation switch.
- 10 Open the gas inlet valve.
- 11 Turn on the boiler and operate for 2 minuets to pre-heat the flue, before commencing any adjustments.
- 12 Make sure that the room thermostat is in the "heat request" position.

13 Open at least one hot water tap fully.




Figure 11.4

14 To enter in the parameters setting mode press at the same time the 2 keys "B" and "D" (Figure 11.4) and hold in for 5 second until the display shows Figure 11.5.



Figure 11.5

- 15 Scroll the various menus using keys "B" or "D" (Figure 11.4) until Ch5 (Chimney sweep) appears on the LCD display (Figure 11.6).
- 16 To enter the selected menu press key "C" (Figure 11.4) for 1 second.



Figure 11.6

17 The letters **LP**, alternating with the minimum heating water temperature (e.g. **45**), appear on the screen indicating the activation of the "chimney sweep function" at minimum power (Figure 11.7).




Figure 11.7

- 18 Allow the analyser to give a stable reading.
- 19 Read the CO₂ % value. It should be between:

Model RINNOVA	Type gas	CO ₂ % value (range)
ADAPTIVE 25C ADAPTIVE 30C ADAPTIVE 35C	Natural (G20)	8,5 - 9,5
	Propane (G31)	9,5 - 10,5

Checking the maximum gas valve setting

20 Press key "D" to vary the output in chimney sweep mode: when the display shows the letters **dP** (chimney sweep active in maximum D.H.W. mode) that alternate with the heating water temperature value (e.g. **60**), the "chimney sweep function" is at maximum output in domestic hot water mode (Figure 11.8).



Warning: If the boiler has a correct CO₂ reading in LP but is incorrect CO₂ in dP before adjusting the boiler ensure the supply pressure is within acceptable limits!




Figure 11.8

- 21 Allow the analyser to give a stable reading.
- 22 Read the CO₂ % value. It should be between:

Model RINNOVA	Type gas	CO ₂ % value (range)
ADAPTIVE 25C ADAPTIVE 30C ADAPTIVE 35C	Natural (G20)	8,5 - 9,5
	Propane (G31)	9,6 - 10,6

If the two values do not coincide with the value shown in the table Gas supply pressures, of the user/installation manual, exit programming mode by pressing the "C" key for 5 seconds and carry out the "Automatic calibration of the gas valve" page 32.

- 23 Switch off the boiler and turn off the hot water tap(s).
- 24 Close the air-flue sampling points.

Important: after the gas pressure checks and any adjustment operations, all of the test points must be sealed.

11.4 Automatic calibration of the gas valve

When replacing the panel board, the fan or gas valve, or parameter **P01** on the control board is changed, the gas valve must be calibrated in order to carry out **CO**₂ calibration at maximum boiler output.

- 1 Turn on the boiler and operate for 2 minuets to pre-heat the flue, before commencing any adjustments.
- 2 Make sure that the room thermostat is in the "heat request" position.
- 3 Open at least one hot water tap fully.




Figure 11.9

To enter in the parameters setting mode press at the same time the 2 keys "B" and "D" (Figure 11.9) and hold in for 5 second until the display shows Figure 11.10.



Figure 11.10

5 Scroll the various menus using keys "B" or "D" (Figure 11.9) until CAF appears on the LCD display (Figure 11.11).



Figure 11.11

Press the key "C" (Figure 11.9) until the StF (Start Full) appears on the LCD display (Figure 11.12).



Figure 11.12

Allow the program to perform the entire process, at the end of which FuF (Full Finish) will be displayed (Figure 11.13).



Figure 11.13

- To exit the parameters menu either.
- wait 15 minutes without pressing any key;
- switch off the electric power supply;
- press the "B" and "D" keys simultaneously for 1 second (Figure 11.9) (return to previous level).

11.5 Checks



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- Check the on-off operators coils
- Remove the front panel of the case.

- 2 Disconnect the electrical connector "3" (Figure 11.2).
- Measure the electrical resistance between the connector pins of the on-off operators as illustrated in Figure 11.14.




Figure 11.14

11.6 Removal of the gas valve



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- Remove the front panel of the case as explained in the section "2.3 Control panel" on page 5, of this manual.
- Disconnect the connector "6" (Figure 11.15), see also connector "3" (Figure 11.2).




Figure 11.15

- Turn off the gas supply and disconnect the gas isolation cock connector from the inlet port of the gas valve.
- Unscrew the connector "8" (Figure 11.15) and remove the
- Unscrew the screws "7" and remove the valve (Figure 11.15).
- Reassemble the valve carrying out the removal operations in reverse order.



Warning: Be careful not to damage the OR gasket of the gas pipe when inserting the pipe in the air box (air/gas mixer).

7 Adjust the gas valve using the flue analyser as described in section "11.4 Automatic calibration of the gas valve" on page 32.

After any service operation on the components of the gas circuit check all the connections for gas leaks.



Warning: After cleaning or replacement as detailed above, it is deemed necessary to undertake a combustion analysis as detailed in section "11.3 Adjustment - Chimney Sweep Function" on page 31.

PRIMARY CIRCUIT FLOW SWITCH

12 PRIMARY CIRCUIT PRESSURE SWITCH

12.1 Function

The Primary circuit pressure switch ("1" in Figure 12.1) function is to check the presence of water in the primary hydraulic circuit and that the pressure is above the minimum.




Figure 12.1


This device is connected to the main electronic control p.c.b. and if, it does not activate the control board will indicate that a fault condition (see section "4.1 Display diagnostic" on page 13 of this manual) has occurred.

12.2 Removal



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove the front and right hand side panels of the case, turn off the flow and return isolation valves and empty the primary circuit.
- 2 Remove the fixing spring "3" (Figure 12.2) and remove the primary circuit pressure switch "4".
- 3 Disconnect the connector "2" (Figure 12.2).



4 Reassemble the primary circuit pressure switch in reverse order of removal.



Warning: to lubricate the O-ring gaskets exclusively use a silicone base grease compatible to be in contact with foods and approved by the local water Authorities.

EXPANSION VESSEL AND PRESSURE GAUGE

13 EXPANSION VESSEL AND PRESSURE GAUGE

13.1 Function

The Expansion vessel ("1" in Figure 13.1) function is to allow for the volume expansion of the C.H. circuit water due to the temperature rise.





Figure 13.1

13.2 Checks

- 1 Turn off the flow and return isolation valves and empty the primary circuit of the boiler.
- 2 Remove the protective cap "2" in Figure 13.2 from the valve on the top of the expansion vessel and connect a suitable air pressure gauge.




3 Check the pre-load pressure and refer to the section *Expansion vessel* in the *User manual and installation instructions* for the correct value.

13.3 Removal of the expansion vessel



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove the front and right hand side panels of the case, turn off the flow and return isolation valves and empty the primary circuit.
- 2 Completely unscrew the connection "5" (Figure 13.3).
- 3 Unscrew the screws "4" and "3" (Figure 13.3).
- 4 Remove the expansion vessel from the front of the boiler.



5 Re-assemble the parts in reverse order of removal.

D.H.W. FLOW SWITCH, FILTER AND FLOW LIMITER

14 D.H.W. FLOW METER, FILTER AND FLOW LIMITER

14.1 Function

The D.H.W. flow meter "1" in Figure 14.1 is a device that generates an electrical signal when hot water is drawn.




Figure 14.1

When the flow rate through the D.H.W. circuit reaches about 2,5 litres/min', the sensor closes the electric contact that switches the boiler D.H.W. operation ON.

14.2 Description and location of parts - (Figure 14.2 - Figure 14.3)

The flow limiter is inserted inside the delivery connection of the D.H.W. heat exchanger.

- 2 Flow meter plug
- 3 Body with flow meter turbine
- 4 O-ring
- 5 Sensor
- 6 Filter




Figure 14.2





Figure 14.3

14.3 Removal of the sensor



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.




- Remove the front panel of the case.
- Remove the sensor holder "7" (Figure 14.4) and disconnect the connectors "8" (Figure 14.5).
- Remove the sensor.

14.4 Checks



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

Sensor operation



- Remove the front panel of the case.
- Don't disconnect the connectors "8".
- Measure the electrical frequency at the leads of the sensor. Without flow rate the electrical frequency must be 0÷32Hz. With flow rate the electrical frequency must be 33÷200Hz.


D.H.W. FLOW SWITCH, FILTER AND FLOW LIMITER

14.5 Removal of the flow meter group and D.H.W. circuit filter



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Please remove the sensor first as previously described and ensure it remains dry.
- 2 Remove the front panel of the case and empty the D.H.W. circuit
- 3 Remove the sensor holder "10" and unscrew the flow meter plug "9" (Figure 14.6).



- Figure 14.6
- 4 Check that body with flow meter turbine "3" (Figure 14.2) rotates freely.
- 5 Reassemble the parts following the removing sequence in reverse order.

TEMPERATURE PROBE

15 NTC HEATING DELIVERY PROBE -NTC MAXIMUM TEMPERATURE, C.H. TEMPERATURE RETURN PROBE NTC, D.H.W. TEMPERATURE PROBE NTC

15.1 Function

The NTC probe has the function of converting the temperature of the water in the hydraulic circuit where it is installed into an electrical signal (resistance).

The relation between temperature and electrical resistance is stated in Figure 15.1.




Figure 15.1

On the boiler there are three temperature probes. One on the output of the primary condensing heat exchanger (NTC heating delivery probe - NTC maximum temperature) "1" in Figure 15.2 and Figure 15.3, one on the return of the primary condensing heat exchanger (C.H. temperature return probe NTC) "2" in Figure 15.2 and Figure 15.4; one on the output of the D.H.W. heat exchanger (D.H.W. temperature probe NTC) "3" in Figure 15.2 and Figure 15.5.




Figure 15.2

15.2 Checks

✓ Temperature-resistance relationship



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

Disconnect the cable from the Temperature probe.


Measure the temperature of the pipe "4" (only NTC heating delivery probe - NTC maximum temperature) where the Temperature probe is located and check the electrical resistance according to the graph in Figure 15.1.

15.3 Removal of the NTC heating delivery probe - NTC maximum temperature



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove all the case panels and the sealed chamber lid.
- 2 Remove the electric connector "5" and the NTC probe "1" (Figure 15.3).
- 3 Reassemble the NTC probe carrying out the removal operations in reverse order.



15.4 Removal of the C.H. temperature return probe NTC




Warning: isolate the boiler from the mains electricity supply before removing any covering or component.


- 1 Remove the front panel of the case and lower the control panel.
- 2 Remove the electric connector "2" and the NTC probe "6" (Figure 15.4)
- 3 Reassemble the NTC probe carrying out the removal operations in reverse order.



Warning: to lubricate the O-ring gaskets exclusively use a silicone base grease compatible to be in contact with foods and approved by the local water Authorities.

TEMPERATURE PROBE





15.5 Removal of the D.H.W. temperature probe NTC



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove the front panel of the case and lower the control panel.
- 2 Empty the D.H.W. circuit of the boiler.
- 3 Remove the electric connector "7" (Figure 15.5)
- 4 Unscrew the NTC probe "3".
- 5 Reassemble the NTC probe carrying out the removal operations in reverse order.



Warning: to lubricate the O-ring gaskets exclusively use a silicone base grease compatible to be in contact with foods and approved by the local water Authorities.

BY-PASS VALVE

16 BY-PASS VALVE

16.1 Function

The By-pass valve "1" in Figure 16.1 is located between the C.H. water flow and return and its function is that of guaranteeing a minimum flow across the primary heat exchanger if the circulation across the C.H. system is completely closed.

The By-pass valve is fitted on the rear side of the diverter group.





Figure 16.1

16.2 Removal



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove all the case panels.
- 2 Empty the primary circuit of the boiler.
- 3 Unscrew the screws "2" and pull the by-pass valve "1" (Figure 16.2).



reversing the order of removal.



Warning: to lubricate the O-ring gaskets exclusively use a silicone base grease compatible to be in contact with foods and approved by the local water Authorities.

4 Reassemble the by-pass valve as illustrated in Figure 16.2

FAN AND AIR BOX

17 FAN AND AIR BOX

17.1 Function

The function of the Fan "1" (Figure 17.1) is to force the mixture of air and gas into the burner.

The function of the Air box "2" is to mix the gas and the air in the right proportion.

The flow rate of the air-gas mixture and consequently the input power of the boiler is proportional to the speed of the fan that is controlled by the electronic control p.c.b.





Figure 17.1

17.2 Removal of the Air box and the Fan



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Turn off the gas supply.
- 2 Remove all the case panels (see section "2 General access and emptying hydraulic circuits" on page 5).
- 3 Unscrew the gas connector "4" and remove the gas pipe "5" (Figure 17.2).
- 4 Disconnect the connectors "3".
- 5 Unscrew the nuts "6".
- 6 Remove the fan "1" with the air box "2".



7 Assemble the Fan carrying out the removal operations in reverse sequence.

Before reassembling ensure the fan gasket (Figure 17.2) is correctly mounted.



Warning: Place the seal on the pipe and offer the pipe with O'ring pre fitted into the manifold rather than inserting the O'ring into the manifold and offering the pipe into it.

After any service operation on the components of the gas circuit check all the connections for gas leaks.



Warning: After cleaning or replacement as detailed above, it is deemed necessary to undertake a combustion analysis as detailed in section "11.3 Adjustment - Chimney Sweep Function" on page 31.

IGNITION AND DETECTION ELECTRODES

18 IGNITION / DETECTION ELECTRODE AND BURNER


E

Electrodes disclaimer.


Note to service engineers: It is required that the burner seal, lip seal and mixing chamber seal along with the flame detection electrode are inspected every year and replaced every 24 months. Failure to inspect the flame detection probe, seals and replace as required may render the guarantee void.

18.1 Function

The ignition / detection electrode "1" is fitted on the left side of the fan-burner group "4".



The burner "6" is fitted on the rear of the fan-burner group "4".



18.2 Removal of the ignition / detection electrode



Warning: isolate the boiler from the mains electricity supply before removing any covering or component

- 1 Remove all the case panels (see section "2 General access and emptying hydraulic circuits" on page 5).
- 2 Disconnect the electrode connector "1" and the earth wire "3" (Figure 18.1).
- 3 Unscrew the screws "2" and remove the electrode "1".
- 4 Assemble the ignition / detection electrode carrying out the removal operation in reverse order.



Warning: A new sealing gasket must be used during refitting of the electrodes on all occasions of removal.

18.3 Removal of the front insulation panel See warning note at the end of this chapter before to remove this part.

- 1 Remove the ignition / detection electrode (see section "18.2 Removal of the ignition / detection electrode" on page 43).
- 2 Remove the front insulation panel by sliding it forward (Figure 18.3).
- 3 Assemble the new front insulation carrying out the removal operation in reverse order. When fitting the new panel ensure that the electrode hole coincide with the hole of the combustion chamber.




Figure 18.3

Caution:

After any periodical servicing or disturbance the combustion chamber silicon seal (Figure 18.3) must be fully inspected and replaced at the discretion of the service engineer.

After any disturbance to the chamber door seal the appliance must undergo a full analytical combustion performance check.

18.4 Removal of the burner



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove the air box and the fan (see section "17.2 Removal of the Air box and the Fan" on page 42).
- 2 Remove the Ignition and detection electrodes (see section "18.2 Removal of the ignition / detection electrode" on page 43).

IGNITION AND DETECTION ELECTRODES

- Unscrew the nuts "5" (Figure 18.1) and remove the cover of the combustion chamber.
- Remove the front insulation panel (see section "18.3 Removal of the front insulation panel" on page 43).
- Unscrew the screws "7" (Figure 18.4) and remove the burner. 5
- Assemble the burner carrying out the removal operation in reverse order. Ensure the burner is correctly located by lining up the locating tab (Figure 18.4).




Figure 18.4

Before reassembling ensure the burner gasket is correctly located.



Warning: After cleaning or replacement as detailed above, it is deemed necessary to undertake a combustion analysis as detailed in section "11.3 Adjustment - Chimney Sweep Function" on page 31).

18.5 Removal of the rear insulation

See warning note at the end of this chapter before to remove this part.



Attention: Cover the inner of the condensing heat exchanger to avoid that dirt and debris fall in the coil.

- Do the operations of section "18.4 Removal of the burner" on page 43 from step 1 to step 3.
- Remove the insulation "8" by pulling it towards the boiler front (Hung it with a screwdriver tip) (Figure 18.5).



Figure 18.5

18.6 Checks

Check of the spark generator.



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

There is not a significant way to verify the integrity of the spark generator. When the fan turns but the burner does not light a possible cause is a faulty spark generator on the main PCB. It would be advisable to replace the Main PCB to rectify the fault.

Check the position of the electrode edges.



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

Check for the correct distance between the metallic edge of the electrode and burner (see Figure 18.6).




Figure 18.6

Check the connection wires

IGNITION AND DETECTION ELECTRODES



Warning: isolate the boiler from the mains electricity supply before removing any covering or component

- 1 Remove all the case panels and the sealed chamber lid.
- 2 Check for the integrity of the insulation of wires which connect the electrode.

The electrode in Figure 18.6 also functions as a sensor for the correct drainage of the condensate.

Should the mentioned electrode come into contact with the condensate water present within the combustion chamber it sends the boiler into safety lockout.

Remove any encrustations and dirt from the detection electrode or replace it if damaged.



In any case, it must be replaced every 2 years. The ignition/detection electrode is not under warranty because it is consumable part.

Warning - Insulation panels material handling care.

Mineral fibres are used in this appliance for the insulation panels of the combustion chamber

Excessive exposure to these materials may cause temporary irritation to eyes, skin and respiratory tract.

Known hazards - Some people can suffer reddening and itching of the skin. Fibre entry into the eye will cause foreign body irritation, which can cause severe irritation to people wearing contact lenses. Irritation to respiratory tract.

Precautions - Dust goggles will protect eyes. People with a history of skin complaints may be particularly susceptible to irritation. High dust levels are only likely to arise following harsh abrasion. In general, normal handling and use will not present high risk, follow good hygiene practices, wash hands before, touching eyes, consuming food, drinking or using the toilet.

First aid - Medical attention must be sought following eye contact or prolonged reddening of the skin.

FLUE TEMPERATURE PROBE NTC AND SAFETY THERMAL FUSE

19 FLUE TEMPERATURE PROBE NTC AND SAFETY THERMAL FUSE

19.1 Function

The Flue temperature probe NTC and Safety thermal fuse "1" in Figure 19.1 and Figure 19.2 senses the temperature of the combustion products that flow through the condensing heat exchanger.




Figure 19.1

If the temperature of the combustion products circuit reaches the limit temperature, the Flue temperature probe NTC reduces the gas flow rate to the burner. The temperature of the combustion products should decrease to a safe value temperature.

In the case that the temperature of the combustion products reaches a potentially dangerous value, the Safety thermal fuse stops the boiler operation (lock-out).

The use of kits different from the original isn't however allowed, since the flue pipes are integral parts of the boiler.




Figure 19.2

A Flue temperature probe NTC and Safety thermal fuse "1" in Figure 19.1 and Figure 19.2 is also connected in series with the Flue temperature probe NTC and acts as a safety device in extreme case of incorrect operation of the Flue temperature control system.

Reaching the breakdown temperature it opens the circuit and locks out the boiler.

In case of intervention of this safety device the heat exchanger (part shown in Figure 19.3) may be damaged and must be re-

placed.




Figure 19.3

19.2 Removal



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove all the case panels.
- 2 Disconnect the connector "2" from the Flue temperature probe NTC and Safety thermal fuse by pressing the plastic hook placed on the side of the connector (Figure 19.2).
- 3 Unscrew and remove the Flue temperature probe NTC and Safety thermal fuse "1" (Figure 19.2) from the condensing heat exchanger.
- 4 Assemble the Flue temperature probe NTC and Safety thermal fuse carrying out the removal operations in reverse sequence.
- 5 Ensure the probe seal is in a good serviceable condition to avoid POC and condensate leakage.

19.3 Checks

Overheat temperature value

- 1 Set the temperature control knobs to their max. position and run the boiler in D.H.W. and C.H.
- 2 Allow the boiler to reach its maximum operating temperature (monitor the temperature gauge on the instrument panel). The boiler should maintain a temperature below that of the Flue temperature probe NTC and Safety thermal fuse and no overheat intervention should occur.
- Temperature-resistance relationship.
- 1 Remove the Flue temperature probe NTC and Safety thermal fuse (see section "19.2 Removal" on page 46).
- 2 Measure the Flue temperature probe NTC and Safety thermal fuse electrical resistance at the ambient temperature and check it according to the graph in (Figure 19.4).

FLUE TEMPERATURE PROBE NTC AND SAFETY THERMAL FUSE




Figure 19.4

CONDENSATE TRAP

20 CONDENSATE TRAP

20.1 Function

The condensate trap "1" in Figure 20.1 and Figure 20.2 allows the discharge of the condensate via the condensate drain pipe avoiding in the mean time the escape of combustion products. A plastic ball closes the trap outlet in case that the trap is empty.




Figure 20.1

If the drain pipe becomes blocked, or condensate cannot drain, the condensate level in the trap rises until it affects the flame detection probe, this will cause the boiler lock-out.

20.2 Check the cleanness of the trap

The condensate drain pipe "1" (Figure 20.2) does not require any particular maintenance but just check:

- 1 That no solid deposits have formed, if so remove them.
- 2 That the condensate drain piping is not clogged.


To clean the inside of the siphon, remove it and turn it upside down to remove any dirt (see section "20.3 Removal" on page 48).

20.3 Removal



Warning: isolate the boiler from the mains electricity supply before removing any covering or component.

- 1 Remove the front and right case panels.
- 2 Using pliers, remove the spring "2" moving it to the left.
- 3 Remove the pipe "3" from the trap "1".
- 4 Remove the trap "1", moving it upwards; from the grommet "4"



5 Reassemble carrying out the removal operations in reverse order.

Figure 20.3

SHORT SPARE PARTS LIST

21 SHORT SPARE PARTS LIST

Key	G.C. part no.	Description	Q.ty	Manufacturer part no.
1		Burner (mod. M300V.2025 SM)	1	BI1713 100
		Burner (mod. M300V.2530 SM - M300V.3035 SM)	1	BI1713 101
2		Expansion vessel	1	BI1462 100
3		Condensing heat exchanger (mod. M300V.2025 SM)	1	BI2002 100
		Condensing heat exchanger (mod. M300V.2530 SM - M300V.3035 SM)	1	BI2112 100
4		Fan		BI1713 102
5		Gas valve	1	BI1713 112
6		Safety valve	1	BI1621 101
7		Main electronic control p.c.b	1	BI2675 108
8		D.H.W. heat exchanger (mod. M300V.2025 SM)	1	BI1001 101
		D.H.W. heat exchanger (mod. M300V.2530 SM - M300V.3035 SM)	1	BI1001 102
9		Motor pump	1	BI2112 103
10		Pump	1	BI2112 104
11		D.H.W. temperature probe NTC	1	BI1001 117
12		C.H. temperature flow probe NTC - Safety Thermostat	1	BI1442 117
13		D.H.W. flow meter	1	BI1621 104
14		D.H.W. flow sensor	1	BI1621 112
15		Primary circuit pressure switch	1	BI1592 115
16		Three way diverter valve (electric actuator)	1	BI1801 102
17		Condensate trap	1	BI1782 107
18		Flue temperature probe NTC and safety thermal fuse	1	BI1782 103
19		Fuse 3,15 AF 250VAC 5x20	1	BI1295 108
20		C.H. temperature return probe NTC	1	BI1442 106
21		Ignition / detection electrode	1	BI1713 107

SHORT SPARE PARTS LIST




Figure 21.1



Biasi UK Ltd Commercial Road Leamore Enterprise Park WALSALL

WS2 7NQ

Sales Tel. 01922 714600 Tech. Service Tel. 01922 714636 www.biasi.co.uk







