

ADVANCE PLUS/ ACTIV A

Taking off Spanner symbol (SERVICING MODE)

ENSURE THAT YOU HAVE NO DEMAND

1. Press and hold down **A, B, C**, together
2. Display goes to **PR 01**
3. Press **A** to scroll to required parameter **PR 28**
4. Press **A + B** together hold down for **4 seconds** then release should go to either **00** or **01 / 02**
5. Press **A** to scroll to **12** = reset for another 12 months
6. To **Memorize** setting press **B** once and release should go to **PR 28**
7. Wait a 10 seconds then Switch Mains Electricity supply OFF from fuse spur and then switch back ON.
8. Spanner symbol should be reset now for another **12 months**.

