


Laser 14 S

code 80000018 N.G.

code 80000019 L.P.G.




Catalogo ricambi


Spare parts list



Tavola 1 - Drawing 1




IT	EN	P.N.
1	FRONTALE LAMIERA	20006069
2	VENTILATORE	20009115
3	KIT FLANGIA	20009119
4	SCAMBIATORE	20009121
5	VALVOLA GAS	20006073
6	FLUSSIMETRO	20007500
7	SONDA NTC	20006048
8	TERMOSTATO LIMITE	20006041
9	GOMMINO	20007242
10	LIMITATORE DI PORTATA	20009123

Tavola 2 - Drawing 2

IT	EN	P.N.
11	SCHEDA ELETTRONICA	20009536
12	FRONTALE	20006060
13	COPERCHIO	20006061
14	MANOPOLA	20006062
15	GUARNIZIONE CRUSCOTTO	20006054

Tavola 3 - Drawing 3



IT	EN	P.N.
16 Elettrodo	ELECTRODE	20009127
17 Bruciatore	BURNER	20009129
18 Kit conversione Gas MTN	GAS CONVERSION KIT NG	20009537
19 Kit conversione Gas GPL	GAS CONVERSION KIT LPG	20009538
20 Kit guarnizioni e mollette	KIT GUARNIZIONI E MOLLETTE	20009771
21 Kit cablaggio	KIT WIRING	20012122